

## DNX571TR

## GPS NAVIGATION SYSTEM INSTRUCTION MANUAL

JVCKENWOOD Corporation

Before reading this manual, click the button below to check the latest edition and the modified pages.

http://manual.kenwood.com/edition/im385/

Take the time to read through this instruction manual.

Familiarity with installation and operation procedures will help you obtain the best performance from your new GPS Navigation System.

#### For your records

Record the serial number, found on the back of the unit, in the spaces designated on the warranty card, and in the space provided below. Refer to the model and serial numbers whenever you call upon your Kenwood dealer for information or service on the product.

Model DNX571TR Serial number \_\_\_\_\_

**US Residence Only** 

### **Register Online**

Register your Kenwood product at www.Kenwoodusa.com



## **What Do You Want To Do?**

Thank you for purchasing the KENWOOD GPS NAVIGATION SYSTEM. In this manual, you will learn various convenient functions of the system.

## Click the icon of the media you want to play.

With one-click, you can jump to the section of each media!



# Contents

Before Use	4
▲ WARNING	. 4
How to Read this Manual	5
Basic Operations	6
Functions of the Buttons on the Front Panel	6
Turning on the Unit	
How to Play Media	
Operating with the Top Menu Screen	
Common Operations	14
Navigation Operation	16
OEM Features Operation	18
DVD/Video CD (VCD)	
Operation	20
DVD/VCD Basic Operation	20
DVD Disc Menu Operation	23
Zoom Control For DVD And VCD	24
DVD Setup	26
CD/Audio and Visual Files/iPod	/
App Operation	30
Music/Video/Picture Basic Operation	30
Search Operation	. 37
Movie Control	42
Pandora® Operation	43
iHeartRadio Operation	46
AUPEO! Operation	49
Apps Operation	51
USB/iPod Setup	53

Radio and HD Radio™ Tuner	
Operation	58
Radio/HD Radio Tuner Basic Operation_	_ 58
Memory Operation	61
Selecting Operation	62
Traffic Information (HD Radio tuner only)	_ 64
Receive Mode (HD Radio tuner only)	64
Bookmark (HD Radio tuner only)	65
SiriusXM® Operation	68
SiriusXM® Basic Operation	68
Memory Operation	_ 71
Selecting Operation	_ 71
Content alert	_ 73
Replay	_ 74
Smart Favorites, TuneStart™	_ 75
TuneScan™	_ 75
SiriusXM Setup	<sub>-</sub> 76
Bluetooth Control	82
Registering And Connecting	82
Bluetooth Unit	
Playing Bluetooth Audio Device	
Using Hands-Free Unit	
Smartphone Link	
Hands-Free Setup	_ 90

Setting Up	92
Monitor Screen Setup	92
System Setup	93
Display Setup	97
Navigation Setup	100
Camera Setup	100
AV Input Setup	101
AV Output Interface Setup	101
Software Information	102
Controlling Audio	104
Setting Audio	104
Controlling General Audio	108
Equalizer Control	108
Zone Control	110
Sound Effect	111
Listening Position	112
Remote control	114
Battery Installation	114
Functions of the Remote control Buttons	

Troubleshooting	118
Problems and Solutions	118
Error Messages	119
Resetting the Unit	121
Appendix	122
Playable Media and Files	122
Status Bar Indicator Items	126
Region Codes in the World	128
DVD Language Codes	129
Specifications	130
About this Unit	133

## **Before Use**

### **A** WARNING



# To prevent injury or fire, take the following precautions:

- To prevent a short circuit, never put or leave any metallic objects (such as coins or metal tools) inside the unit.
- Do not watch or fix your eyes on the unit's display when you are driving for any extended period.
- If you experience problems during installation, consult your Kenwood dealer.



### Precautions on using this unit

- When you purchase optional accessories, check with your Kenwood dealer to make sure that they work with your model and in your area.
- You can select language to display menus, audio file tags, etc. See <u>Language setup</u> (P.95).
- The Radio Data System or Radio Broadcast Data System feature won't work where the service is not supported by any broadcasting station.



## Protecting the monitor

To protect the monitor from damage, do not operate the monitor using a ball point pen or similar tool with the sharp tip.



### Cleaning the unit

If the faceplate of this unit is stained, wipe it with a dry soft cloth such as a silicon cloth. If the faceplate is stained badly, wipe the stain off with a cloth moistened with neutral cleaner, then wipe it again with a clean soft dry cloth.



 Applying spray cleaner directly to the unit may affect its mechanical parts. Wiping the faceplate with a hard cloth or using a volatile liquid such as thinner or alcohol may scratch the surface or erase screened print.

### **Lens fogging**

When you turn on the car heater in cold weather, dew or condensation may form on the lens in the disc player of the unit. Called lens fogging, this condensation on the lens may not allow discs to play. In such a situation, remove the disc and wait for the condensation to evaporate. If the unit still does not operate normally after a while, consult your Kenwood dealer.



### Precautions on handling discs

- Do not touch the recording surface of the disc.
- Do not stick tape etc. on the disc, or use a disc with tape stuck on it.
- · Do not use disc type accessories.
- Clean from the center of the disc and move outward.
- When removing discs from this unit, pull them out horizontally.
- If the disc center hole or outside rim has burrs, use the disc only after removing the burrs with a ballpoint pen etc.
- · Discs that are not round cannot be used.





- 8-cm (3 inch) discs cannot be used.
- Discs with coloring on the recording surface or discs that are dirty cannot be used.
- This unit can only play the CDs with



This unit may not correctly play discs which do not have the mark.

 You cannot play a disc that has not been finalized. (For the finalization process see your writing software, and your recorder instruction manual.)

## How to Read this Manual

Return to the Top page
CD/Audio and Visual Files/iPod/App Operation

### **Search Operation**

You can search music, video or picture files by the following operations.

#### NOTE

 If you use a remote control, you can jump directly to the desired track/file with entering the track/ folder/file number, play time, etc. For details, see Direct search mode (P.115).

## List search

You can search tracks, folders, and files according to hierarchy.

1 Touch [ ] in the control screen. The search type screen appears.

#### 2 Touch desired search way.



List Control screen appears.

#### 3 Touch the desired folder.



4 Touch desired item from the content

Playback starts.

### Other search

When you want to narrow the list down, there are other search ways.

This function is not available when music CD is the current source.

30

#### Link header

You can refer each section or top page with one-click.

#### **Operation title**

Introduces the function.

#### NOTE

Introduces some tips, notes, etc.

#### Reference mark

Displayed in blue notes.

With one-click, you can jump to the article related to the current section.

#### **Operation procedure**

Explains necessary procedures to achieve the operation.

- < >: Indicates the name of panel buttons.
- [ ]: Indicates the name of touch keys.

#### Screen shot

Shows some screen shots displayed during operation for reference.

The area or keys to touch are surrounded with a red frame.


#### NOTE

 The screens and panels shown in this manual are examples used to provide clear explanations of the operations.
 For this reason, they may be different from the actual screens or panels used, or some display

actual screens or panels used, or some display patterns may be different.

## **Basic Operations**

## Functions of the Buttons on the Front Panel



#### NOTE

• The panels shown in this guide are examples used to provide clear explanations of the operations. For this reason, they may be different from the actual panels.


#### How to insert a microSD Card

- 1) Open the 18 microSD card slot cover as the illustration in the right.
- Hold the microSD card with the label facing up and the notched section right, and insert it into the slot until it clicks.

### • To eject the card:

Push the card until it clicks and then remove your finger from the card.

The card pops up so that you can pull it out with your fingers.



Number	Name	Motion
1	Disc insert slot	A slot to insert a disc media.
2	▲ (Eject)	<ul><li>Ejects the disc.</li><li>Pressing for 1 second ejects the disc forcibly.</li></ul>
3	∇ (Reset)	<ul> <li>If the unit or the connected unit fails to operate properly, the unit returns to factory settings when this button is pressed (P.121).</li> <li>This indicator flashes when the vehicle ignition is off (P.96).</li> </ul>
4	MENU	<ul> <li>Displays the Top Menu screen (P.12).</li> <li>Pressing for 1 second turns the power off.</li> <li>When the power off, turns the power on.</li> </ul>
5	NAV	Displays the navigation screen.     Pressing for 1 second switches AV out sources.
6	Volume Knob	<ul> <li>Turning adjusts volume up or down.</li> <li>Pressing switches attenuation of the volume on/off.</li> <li>Pressing for 1 second displays Graphic Equalizer screen (P.109).*1</li> </ul>
7	TEL	<ul> <li>Displays the Hands Free screen (P.85).</li> <li>Pressing for 1 second displays the Voice Recognition screen. (P.88) *2</li> </ul>
8	microSD card slot	A microSD card slot for upgrading the map. For how to upgrade the map, refer to the instruction manual of the navigation system.


<sup>\*1</sup> The display may not switch to the Graphic Equalizer screen in some conditions.

<sup>\*2 [</sup>TEL] button can also be used to switch to the rear view camera or turn off the display. See *User interface (P.94)*.

## Turning on the Unit

The method of turning on is different depending on the model.

1 Press the <MENU> button.



The unit is turned on.

• To turn off the unit:

Press the <MENU> button for 1 second.

If it is your first time turning the unit on after installation, it will be necessary to perform *Initial setup (P.9)*.

### **Initial setup**

Perform this setup when you use this unit first time or when you reset the unit (P.121).

### 1 Set each item as follows.





#### Locale

Select the country for the navigation system.

The language, the distance unit, and the gasoline unit are set.

After setting, touch [Enter].

- 1) Touch [SET].
- ② Select the desired country.

#### Language

Select the language used for the control screen and setting items. Default is "American English (en)".

- ①Touch [SET].
- ② Touch [◄] or [►] to select the desired language.
- ③ Touch [Enter].

For detailed operation, see Language setup (P.95).

#### **AV-IN SETUP**

Select the source connected to AV-IN.

- 1) Touch [SET].
- ② For AV-IN Interface, touch [Rear Camera] or [AV-IN] to select the source.
- ③ For AV-IN Name, touch [◄] or [▶] to select the name.

For detailed operation, see AV Input Setup (P.101).

#### Color

Set the screen and button illumination color. You can select whether to allow color scan operation or select a fixed color for operation.

- ①Touch [SET].
- ② Touch [ON] or [OFF] of [Panel Color Scan].
- ③ If you want to change color, touch [SET] of [Panel Color Coordinate].
- ④ Touch your desired color and [♠].

For detailed operation, see Panel color coordinate (P.98).

#### Camera

Set the parameters for the camera.

- ①Touch [SET].
- ② Set each item and touch [ ].

For detailed operation, see **Camera Setup (P.100)**.

#### **OEM SETUP**

This function requires a commercial adaptor. Consult your Kenwood dealer for details.

## 2 Touch [Finish].




#### NOTE

• These settings can be set from the SETUP menu. See Setting Up (P.92).

## How to Play Media

### Music CD and disc media

1 Insert the disc into the slot.




The unit loads the disc and playback starts.

To eject the disc:
Press the <≜> button.



#### **USB** device

Connect the USB device with the USB cable.



The unit reads the device and playback starts.

● To disconnect the device:

Touch [♠] on the screen and disconnect the device from the cable.

#### **iPod**

1 Connect the iPod.

The unit reads the iPod and playback starts.

#### NOTE

- For the details of the necessary cable and adapter to connect with iPod/iPhone, refer to <u>Music/</u> <u>Video/Picture Basic Operation (P.30)</u>.
- To disconnect the iPod/iPhone connected with the cable:

Touch [ ] on the screen and then touch [ ]. Disconnect the iPod from the cable.

## **O**perating with the Top Menu Screen

Most functions can be performed from the Top Menu screen.

1 Touch [Menu] on any screen.



#### NOTE

 If [Menu] is not displayed during video/picture playback, press the <MENU> button.
 (P.6)

Top Menu screen appears.



#### NOTE

 Top Menu screen can be changed by flicking left or right.

- Customizing Top Menu screen
   You can arrange the position of the source icons as you like.
  - Touch and hold the icon which you want to move to go into the customizing mode.
  - 2. Drag it where you want to move.

#### Customizing mode screen



## From this screen, you can perform the following functions.

Function	lcon	Operation
Switch the audio source	USB Pod HD RADIO etc.	Touch the icon of the desired source.
Switch the video source	VIDEO1 HDWI / MHL etc.	Touch the icon of the desired video source.
Switch the application installed in the iPhone/iPod or Android.	Pandora Radio AUPEOL etc.	Touch the icon of the desired application.
Switch the Apps source	APPS	Touch the icon of the desired App source.
Enter setup mode	SETUP Audio etc.	Touch the icon of the desired setup function.
Display navigation screen	O.5 mi Sunset Blvd	Touch [NAV] or navigation information.
Turn off all audio function	STANDBY	Touch [STANDBY].
Vehicle information display	OEM Features	Touch [OEM Features].

## **C**ommon Operations

Introduces the common operations.

#### General

There are some functions which can be operated from most screens.



#### [Menu] (Screen control)

Returns to the Top Menu screen. Touching for at least 1 second displays the Screen Control screen. (Even when an image is displayed, touching for at least 1 second displays the Screen Control screen.)

### (RETURN)

Returns to previous screen.

### (common menu key)

Touch to display the common menu. The contents of the menu are as follows.

- : Displays the SETUP Menu screen.
- : Displays the Audio Control Menu screen.
- Displays the control screen of current source. Icon feature differs depending on the source.
- : Closes the menu.

#### List screen

There are some common function keys in the list screens of most sources.





Scrolls the displayed text.



Touch keys with various functions are displayed here.

Displayed keys differ depending on the current audio source, status, etc. For examples of functions of each key, refer to the table below.

Key	Function
All ⊳	Lists all the music in the lower hierarchy.
	Moves to the upper hierarchy.
	Displays current category folder.
A M	Displays music/picture/movie file list.

## **Flick scrolling**

You can scroll the list screen by flicking the screen up/down or right/left.





## **Navigation Operation**

For details on the navigation function, please refer to the Navigation Instruction Manual.

## Display the navigation screen

1 Press the <NAV> button.



The navigation screen appears.

### Control audio from the navigation screen

You can control audio sources while the navigation screen is displayed.

Also, you can view the navigation information while the source control screen is displayed.

1 Touch the information bar.



The navigation screen with audio information appears.

2 Touch [ 💹 ] or [ 🔝 ] in the navigation screen.



Touching this area displays the audio screen.

: Displays the navigation and control keys of the current source.



: Displays the navigation and current video/picture playback display.



#### NOTE

- The screen switches between playback screen and camera view each time the viewing area is touched.
- Touching the source icon in the bottom of the screen displays the full audio screen.

# • To return to the full navigation screen: Touch [ ].

#### NOTE

· For details on control keys, refer to the instructions in each section.

## **OEM Features Operation**

By connecting this unit to the bus system of the vehicle using an iDataLink (commercially available), this unit can access the satellite radio source provided for the vehicle and vehicle information can be displayed on this unit.

- Touch [Menu] on any screen.
  Top Menu screen appears.
- Touch [OEM Features] in the Top Menu screen.

  OEM Features screen appears.



Displays the control screen of the satellite radio source provided for the vehicle.




D: Displays the control screen of the Bluetooth Hands Free function provided for the vehicle.




: Displays the control screen of the media player source provided for the vehicle.



Displays the control screen of the Bluetooth streaming source provided for the vehicle.







Displays information about the Parking Distance Sensor of the vehicle.



: Displays information about the air conditioner of the vehicle.



: Displays information about the tire pressures of the vehicle.



#### NOTE

• Displayable screens, button names, and screen names vary depending on the type of the connected iDataLink and the model of the vehicle. For more details, access the following URL: www.idatalink.com/


## DVD/Video CD (VCD) Operation

## **DVD/VCD Basic Operation**

Most functions can be controlled from the source control screen and playback screen.

#### NOTE

- Set the remote control mode switch to DVD mode before starting operation, see **Switching the operation mode** (P.115).
- The screen shot below is for DVD. It may be different from the one for VCD.



#### 1 Information display

Displays the following information.

- Title #, Chap #: DVD title and chapter number display
- Track #/Scene #: VCD track or scene number display Scene # is displayed only when Playback control (PBC) is on.
- ▶, ▶▶, ▶▶I, ■, etc.: Current play mode display

The meanings of each icon are as follows;  $\triangleright$  (play),  $\triangleright \triangleright$  (fast forward),  $\triangleleft \triangleleft$  (fast backward),

- ▶► (search up), ► (search down), (stop), (resume stop), (pause), ► (slow playback),
- ◀I (slow reverse playback).

Touch this area to display the disc label name.

#### 2 Multi function key

Touch to switch the multi function menu. For details on the menu, see *Multi function menu* (P.22).

#### 3 Multi function menu

Various functions can be performed by using keys in this area. For details on the keys, see <u>Multifunction menu</u> (P.22).

#### 4 Control switching key

Unavailable in DVD/VCD source.

#### 5 Sub function menu

The following functions can be performed by using keys in this area.

• Repeats the current content: Touch [ ]. Each time you touch the key, repeat mode switches in the following sequence;

DVD: "title repeat" , "chapter repeat" , "function off"

VCD (PBC On): Does not repeat

VCD (PBC Off): "track repeat" , "function off"

- Hides all keys: Touch [ ].
- Fast forward or fast backward: Touch [◄◄] or [▶►]. Each time you touch the key, the speed changes; standard, 2 times, 3 times.
- Confirms play time: See #:##:##.

DVD: You can switch the time display between title play time, chapter play time, and title remaining time. Each time you touch, the display switches between "T #:##:##" (title play time display), "C #:##:##" (chapter play time display), and "R #:##:##" (title remaining time display).

As well as the time display, the bar indicating current location appears.

VCD (PBC off): You can also confirm disc remaining time by touching time display. Each time you touch, the display switches between "P ##:##" (play time display) and "R ##:##" (disc remaining time).

• Confirms the current location: See the bar in center (DVD only). The bar does not appear when the time display is remaining time display.

#### 6 Searching area

Touch to search the next/previous content.

Scrolling from center of display to left or right performs fast backward or fast forward. Each time you touch each area, the speed changes; standard, 2 times, 3 times. To stop fast backward/forward, touch center of the display.

#### 7 Menu display area

This area functions differently depending on the current status.

- During DVD playback: Displays the DVD menu. During the menu display, displays the highlight control screen (P.23).
- During VCD playback: Displays the Zoom Control screen (P.24).

#### 8 Key display area

Touch to display the last control screen.

#### 9 Screen setup display area

Touch and hold to display the screen control screen. See Monitor Screen Setup (P.92).

#### NOTE

• If you use a remote control, you can jump directly to the desired image with entering the chapter number, scene number, play time, etc (P.115).



DVD



The functions of each key are as follows.

#### 

Searches the previous/next content.

#### [**▶**II]

Plays or pauses.

### [**◄**I] or [I▶] (DVD only)

Plays in slow motion forward or backward.

#### 

Stops playback. When touched twice, the disc is played from the beginning when you play it the next time.

#### [PBC] (VCD only)

Turn Playback control (PBC) on or off.

## [ SETUP]

Touch to display the SETUP Menu screen. See Setting Up (P.92).

## [ O AUDIO]

Touch to display the Audio Control screen. See Controlling Audio (P.104).

### [REAR 🕩]

Touch to mute the rear speaker.

## **DVD Disc Menu Operation**

You can set up some items in the DVD-VIDEO disc menu.

### 1 Touch illustrated area during playback.



Menu Control screen appears.

### 2 Perform desired operation as follows.



#### Displays the top menu

Touch [Top].\*

#### Displays the menu

Touch [Menu].\*

#### Displays the previous menu

Touch [Return].\*

#### **Enters selected item**

Touch [Enter].

### **Enables direct operation**

Touch [Highlight] to enter the highlight control mode (P.23).

#### Moves the cursor

Touch  $[\blacktriangle]$ ,  $[\blacktriangledown]$ ,  $[\blacktriangleright]$ .

\* These keys may not function depending on the disc.

## Highlight control

Highlight control lets you control the DVD menu by touching the menu key directly on the screen.

- 1 Touch [Highlight] in the Menu Control screen.
- 2 Touch desired item on the screen.



#### NOTE

• The highlight control is cleared automatically if you do not operate for a constant time.

## DV

### DVD play mode setting

You can select DVD play mode.

Touch [Next] in the Menu Control screen.



Menu Control 2 screen appears.

2 Touch the key which corresponds to desired setting item.



#### Switches the subtitle language

Touch [Subtitle]. Each time you touch this key, language is switched.

#### Switches the audio language

Touch [Audio]. Each time you touch this key, language is switched.

#### Controls zoom ratio

Touch [Zoom]. For details, see <u>step2 in Zoom</u> Control For DVD And VCD (P.24).

#### Switches the picture angle

Touch [Angle]. Each time you touch this key, picture angle is switched.

#### **Exits menu control**

Touch [Exit].

#### Displays the Menu Control 1 screen

Touch [Previous].

## **Zoom Control For DVD And VCD**

You can enlarge Playback screen for DVD and VCD.

1 For VCD, touch illustrated area during playback.



Zoom Control screen appears.

#### NOTE

 For DVD, please refer to <u>DVD play mode setting</u> (P.24) to display the Zoom Control screen.

### 2 Perform desired operation as follows.



#### Switches zoom ratio

Touch [Zoom].

For DVD, changes the zoom ratio at 4 levels; Off, 2 times, 3 times, 4 times.

For VCD, changes the zoom ratio at 2 levels; Off. 2 times.

#### Scrolls the screen

Touch  $[\blacktriangle]$ ,  $[\blacktriangledown]$ ,  $[\blacktriangledown]$ , or  $[\blacktriangleright]$  to scroll the screen in the direction you touch.

#### Exits menu control

Touch [Exit].

#### Displays the previous menu\*

Touch [Return].

\* This function may not be performed depending on the disc.

#### NOTE

• You cannot touch the menu keys directly on the screen when zooming.


### **DVD Setup**

You can set up the DVD playback functions.

#### NOTE


- Each operation in this section can be started from the Top Menu screen. For details, see **Operating** with the Top Menu Screen (P.12).
- Some setup items can only be set in standby mode.
- 1 Touch [ ] in the control screen.

  Multi function menu appears.
- **2 Touch [SETUP].**SETUP Menu screen appears.
- 3 Touch [Source].



Source SETUP Menu screen appears.

- **4 Touch [DVD SETUP] in the list.**DVD SETUP screen appears.
- 5 Set each item as follows.



#### Menu/Subtitle/Audio Language\*

See Language setup (P.27).

### **Dynamic Range Control\***

Sets the dynamic range.

Wide: The dynamic range is wide.

Normal: The dynamic range is normal.

**Dialog (Default)**: Makes the total sound volume larger than other

modes. This is effective only when you are using Dolby Digital software.

#### **Angle Mark**

Sets an angle mark display.

ON (Default): An angle mark appears.

OFF: An angle mark does not appear.

#### **Screen Ratio\***

Sets the screen display mode.

16:9 (Default): Displays wide pictures.

- **4:3 LB**: Displays wide pictures in the Letter Box format (having black stripes at the top and bottom of screen).
- **4:3 PS**: Displays wide pictures in the Pan & Scan format (showing pictures cut at the right and left ends).

#### Parental Level\*

See Parental level (P.28).

#### **DISC SETUP**

See Disc setup (P.28).

#### **Stream Information**

Displays the present source information. The stream (Dolby Digital, Linear PCM, MPEG, WMA or AAC) appears.

\* These items are disabled when a DVD is inserted.

## Language setup

This setting is for the language used in the menu, subtitle, and voice. You cannot setup these items during DVD playback.

- Touch [SET] of the desired item;
   [Menu Language], [Subtitle Language],
   [Audio Language].
  - Language Set screen appears.
- 2 Enter the desired language code and touch [Enter].



For language code, refer to <u>DVD Language</u> Codes (P.129).

Sets the entered language and returns to the DVD SETUP screen.

#### NOTE

- To cancel the setup and return to the previous screen, touch [Cancel].
- To clear the entered code, touch [Clear].
- To set the DVD's original language for audio language, touch [Original].

## Parental level

Sets a parental level. You cannot setup this item during DVD playback.

- 1 Touch [SET] of [Parental Level].
  Parental Pass screen appears.
- 2 Enter the parental code and touch [Enter].

Parental Level screen appears.

#### NOTE

- The parental code is set to "0000" as default.
- To cancel the setup and return to the previous screen, touch [Cancel].
- To clear the entered code, touch [Clear].
- · Current parental level appears as [Level#].

## 3 Touch [◄] or [►] to select a parental level.



#### NOTE

- If a disc has higher parental lock level, you need to enter the code number.
- The parental lock level varies depending on a loaded disc.
- If a disc has no parental lock, anybody can play it back even when you have set the parental lock.

## Disc setup

Performs setup when using disc media.

- 1 Touch [SET] of [DISC SETUP].
  DISC SETUP screen appears.
- 2 Select an option as follows.



#### **CD Read**

Sets the motion of this unit when a music CD is played.

- (Default): Automatically recognizes and plays back an audio file disc, a DVD or a music CD
- 2: Forcibly plays back a disc as a music CD.

  Select [2] if you wish to play a music CD having a special format or if you cannot play a disc in [1] position.

#### On Screen DVD

Sets an on-screen display.

**Auto**: When updated, information appears for 5 seconds.

OFF (Default): Information does not appear.

#### NOTE

- [CD Read] is not available when a disc is in the
- You cannot play an audio file/VCD disc in the [2] position. Also, you may not play some music CDs in the [2] position.

## CD/Audio and Visual Files/iPod/App Operation

## **Music/Video/Picture Basic Operation**

Most functions can be controlled from the source control screen and playback screen.

#### NOTE

- Set the remote controller mode switch to AUD mode before starting operation, see <u>Switching the operation</u> mode (P.115).
- To connect the Android device with this unit, the cable (sold separately) and the profile which your Android device supports are necessary as follows:
- · To listen to music and watch video of APPS source
  - -MHL device
  - -KCA-MH100
  - -Bluetooth profile: SPP
- · To listen to music of APPS source
  - -Bluetooth profile: A2DP
  - -Bluetooth profile: SPP
- · To listen to music of Bluetooth Audio source
  - -Bluetooth profile: A2DP
  - -Bluetooth profile: AVRCP
- To connect the iPod/iPhone with this unit, the cable, adapter (both sold separately), and the profile which your iPod/iPhone supports are necessary as follows:
- · To listen music and watch video with Lightning connector device
  - -Lightning Digital AV Adapter
  - -KCA-HD100
  - -KCA-iP103
  - -Bluetooth profile: SPP
- To listen music with Lightning connector device
  - -KCA-iP103
- $\bullet$  To listen music and watch video with 30-pin connector device
  - -KCA-iP202
- $\bullet$  To listen music with 30-pin connector device
  - -KCA-iP102
- · To listen to music via Bluetooth
  - -Bluetooth profile: A2DP
  - -Bluetooth profile: SPP

When connecting with Lightning Digital AV Adapter or Apple 30-pin Digital AV Adapter some applications can be controlled from this unit. The operable functions depend on the application.

- Do not leave the cable or the adapter made by other makers inside the car. It might lead the malfunction caused by heat.
- Some settings are necessary to meet the connected iPod/iPhone or Android device. Refer to <u>iPod/iPhone</u> connection setup (P.54) and Application link setup (P.56).

#### See the following sections for each source operation.


- Music CD (P.31)
- Disc media (P.31)
- USB device (P.33)
- iPod (P.33)
- Pandora (P.43)
- iHeartRadio (P.46)
- AUPEO! (P.49)

#### • Apps (P.51)

### Music CD and disc media

#### NOTE

- In this manual, "Music CD" will be referred to as the general CDs which include music tracks in. "Disc media" will be referred to as CD/DVD disc which includes audio, picture or video files.
- The screen shot below is for CD. It may be different from the one for disc media.



#### 1 Information display

Displays the following information.

- Track #: Each time you touch this area, display switches between current track number, text, etc.
- ▶, ▶▶, ▶▶I, ■, etc.: Current play mode display

The meanings of each icon are as follows;  $\blacktriangleright$  (play),  $\blacktriangleright \blacktriangleright$  (fast forward),  $\blacktriangleleft \blacktriangleleft$  (fast backward),  $\blacktriangleright \blacktriangleright$  (search up),  $\blacktriangleright \blacktriangleleft$  (search down),  $\blacksquare$  (stop),  $\blacksquare$  (resume stop),  $\blacksquare$  (pause).

#### 2 Movie display area/Control switching area

Touch to switch between the Simple Control and List Control screen.

#### 3 Multi function key

Touch to switch the multi function menu. For details on the menu, see Multi function menu (P.35).

#### 4 Multi function menu

Various functions can be performed by using keys in this area. For details on the menu, see <u>Multifunction menu (P.35</u>).

#### 5 Sub function key

Touch to display "Sub function menu" (7 in this table).

#### 6 Track information

Displays the information of the current track.

For music CD and disc media, you can switch the current track information and the current folder list by touching the list switching key (8 in this table).


However, only "No Information" is displayed for music CD.

#### 7 Sub function menu

Various functions can be performed by using keys in this area. For details on the keys, see <u>Sub function</u> menu (P.36).

#### 8 List switching key

Touch to switch between the track list and the CD-TEXT display (CD)/ID3 tag information (disc media only).



#### 9 Searching file area (disc media only)

Touch to search the next/previous file.

Scrolling from center of display to left or right performs fast backward or fast forward. Each time you touch each area, the speed changes; standard, 2 times, 3 times. To stop fast backward/forward, touch center of the display.

#### 10 Menu display area (disc media only)

Touch to display the disc menu. For details, see Movie Control (P.42).

#### 11 Key display area (disc media only)

Touch to display the last control screen.


#### 12 Screen setup display area

Touch and hold to display the screen control screen. See *Monitor Screen Setup (P.92)*.

## USB device and iPod

#### NOTE

• The screen shot below is for USB device. It may be different from the one for iPod.



#### 1 Information display

Displays the following information.

- Current file name: Each time you touch this area, display switches between file number/folder number and file name.
- ▶, etc.: Current play mode display
   The meanings of each icon are as follows; ▶ (play, searching), II (pause).

#### 2 Artwork/Control switching area

The picture data is displayed if available from the current file. When the picture is not available, "No Photo" is displayed.

Touch to switch between the Simple Control and List Control screen.

#### 3 Multi function key

Touch to switch the multi function menu. For details on the menu, see Multi function menu (P.35).

#### 4 Multi function menu

Various functions can be performed by using keys in this area. For details on the keys, see <u>Multifunction menu</u> (P.35).

### 5 Sub function key

Touch to display "Sub function menu" (7 in this table).

#### 6 Contents list

Displays the list and contents. The contents of the list differ depending on the playback status and source.


When you select the video source on the device connected with the Lightning connecter, the source is switched to Apps (*P.51*) automatically.

#### 7 Sub function menu

Various functions can be performed by using keys in this area. For details on the keys, see <u>Sub function</u> menu (P.36).

#### 8 List switching kev

Touch to switch between the file list and the current file information.



### 9 Searching file area (picture/video file only)

- Touch to search the next/previous file.
- During slide show in USB mode, touching each area searches the next/previous music file.
- Scrolling from center of display to left or right performs fast backward or fast forward. To stop fast backward/forward, touch center of the display. This function is not available when there is no music file in the current folder.

#### 10 Key display area (picture/video file only)

Touch to display the last control screen.

#### 11 Screen setup display area

Touch and hold to display the screen control screen. See Monitor Screen Setup (P.92).

## Multi function menu

#### Music CD

#### **iPod**



#### Disc media

#### **USB** device



The following functions can be performed by using keys in this area.

## 

Searches track/file. For details on search operation, see **Search Operation (P.37)**.

#### 

Searches the previous/next track/file.

#### [**>**][II]/[**>**II]

Plays or pauses.

#### [ ] (music CD and disc media only)

Stops playback.

### [▲] (USB device and iPod only)

Touch to disconnect the device. For details, see How to Play Media (P.11).

### [ ] [ ] (disc media and USB device only)

Searches previous/next folder.

### [ 📦 ] (picture files in USB device only)

During picture playback, switches to picture display.

### [ SETUP]

Touch to display the SETUP Menu screen. See **Setting Up** (P.92).

## [ AUDIO]

Touch to display the Audio Control screen. See Controlling Audio (P.104).

## [REAR (X)

Touch to mute the rear speaker.

### CD/Audio and Visual Files/iPod/App Operation







The following functions can be performed by using keys in this area.



Repeats the current track/folder. Each time you touch the key, repeat mode switches in the following sequence;

CD: "track repeat" , "repeat off"

iPod: "song repeat" all songs repeat" repeat off" bisc media, USB device: "file repeat" , "folder repeat" , "repeat off" .

### [ ] (USB device and iPod only)

Searches track from the album artwork list. For details on search operation, see **Search from album artwork (P.40)**.

### [ ] (During video file playback only)

Hides all keys.

### [◄◄] [▶▶] (Music CD and disc media only)

Fast forward or fast backward.

### [《》][》》] (USB device and iPod only)

Plays the previous or next album in Favorite list (P.41).

### #:##:## or ##:##

Confirms play time.

During music CD playback, you can also confirm disc remaining time by touching time display. Each time you touch, the display switches between "P ##:##" (track play time display) and "R ##:##" (disc remaining time).

### [X\$]

Randomly plays all tracks in current folder/disc or in current playlist in the connected iPod.

Each time you touch the key, random mode switches in the following sequence;

CD: "track random" x, "random off"

Disc media, USB device: "file random" , "random off"

iPod: "track random" 🔀 , "album random" 📿 , "random off"

### Status bar in center (USB device and iPod only)

Confirms the current location.

During USB device and iPod playback, you can drag the circle left or right to change the playing position.

### **Search Operation**

You can search music, video or picture files by the following operations.

#### NOTE

 If you use a remote control, you can jump directly to the desired track/file with entering the track/ folder/file number, play time, etc. For details, see Direct search mode (P.115).

## List search

You can search tracks, folders, and files according to hierarchy.

### 1 Touch illustrated area.



List Control screen appears.

### 2 Touch desired track/file.



Playback starts.

### NOTE

- For disc media, you can switch the file list and folder list by touching [ ].
- For disc media, you cannot display the list during random play and stop.

## Other search

When you want to narrow the list down, there are other search ways.

This function is not available when music CD is the current source.


# 1 Touch [ ] in the control screen. The search type screen appears.

### 2 Touch desired search way.

**USB** device



### iPod



The list sorted in the way you selected appears.

See the following sections for each operation.

- [Category List]: You can search a file by selecting category (P.38).
- [Link Search]: You can search a file of same artist/album/genre/composer as the current track (P.38).
- [Folder List]: You can search a file according to hierarchy (P.39).
- [Thumbnail Viewer]: You can search a picture file (P.39).

#### NOTE

• For disc media, you can display the folder list directly by touching [ . ].

# Category search (USB device and iPod only)

1 Touch the desired category from the left part of the screen.



- 2 The list is sorted by selected category.
- 3 Touch desired item.

Playback starts.

#### NOTE

- To narrow the search you can select a letter from the alphabet list in the center of the display.
- For operations in the list screen, see **Common Operations (P.14)**.

### Link search (USB device and iPod only)

1 Touch the desired item from the left part of the screen. You can select from artist, album, genre and composer.



The list corresponding to your selection appears.

#### NOTE

- The list is sorted by the way you selected.
  - artist: Displays the album list of the artist.
- album: Displays all tunes of the current album.
- **genre**: Displays the artists list in which artists belong to the same genre.
- composer: Displays the album list of the composer of the current file.
- 2 Touch to select desired item in the list. Repeat this step until you find the desired file.

#### NOTE

- To narrow the search you can select a letter from the alphabet list in the center of the display.
- For operations in the list screen, see **Common Operations (P.14)**.

# Folder search (USB device and disc media only)

### 1 Touch the desired folder.



Folders in the selected source are displayed in the center.

When you touch a folder its contents are displayed.

The hierarchy till the current folder is displayed on the left.

# 2 Touch desired item from the content list.

Playback starts.

#### NOTE

• For operations in the list screen, see **Common Operations** (P.14).

### Picture search (USB device only)

### 1 Touch the desired picture.



The selected picture appears in full screen. See number 9-10 in <u>USB device and iPod</u> (P.33) for operation of picture screen.

# Search from album artwork (USB device and iPod only)

You can search music files by selecting the album artwork.

1 Touch [ ].
Sub function menu appears.

### 2 Touch [ ].



Favorite screen appears.

### 3 Touch desired artwork in the lower line.



#### NOTE

• The key in the upper side of the screen functions differently depending on the status.

### When [Load Albums] appears:

You have not yet loaded any artworks. Touch the key to start loading.

### When [Load More Albums] appears:

Some artworks are not loaded. Touch the key to load all artworks. If you touch the key, the track being played may stop and another track may start playback.

### When the key does not available:

All artworks are already loaded.

### 4 Touch [►] on the selected artwork.

The first song in the album is played. In addition, you can create your original playlist from this screen. For details, see *Favorite list (P.41)*.

#### NOTE

- After all tracks in the album are played, the same album is played again from the first track.
- The albums with no photo are not displayed.

### **Favorite list**

You can create an original playlist of your favorite 10 albums by selecting album artworks.

 Touch and drag the desired album artwork in the lower line to the upper line.



Selected album is registered to the favorite list.

### NOTE

- The added album is placed on the extreme right.
- You cannot register the same album already registered to the favorite list.
- Up to 10 albums can be registered to the list.
- 2 Touch the desired artwork in the favorite list.



Selected album is played and the control screen appears.

### NOTE

- The favorite list is played to the right starting with the selected album.
- To delete the album from the favorite list, touch and drag it to the lower line.
- You can change the playing order of the favorite list by dragging the artwork in the list.
- The favorite list mode is canceled in the following situations.
- Playing another album from other list (folder list, category list, etc.)
- Playing another album by touching the artwork in the lower line in the artwork list screen.
- The favorite list mode resumes after disconnecting/connecting the device or turning on/off. File being played, playing time code, favorite list contents, favorite list order, etc. resumes if file configuration of the device is not changed.

### **Movie Control**

You can adjust the movie playback from a disc media.

1 In the playback screen, touch illustrated area.



Movie Control screen appears.

2 Perform desired operation as follows.



### Changes subtitle language

Touch [Subtitle].

### Changes audio language

Touch [Audio].

### Exits the menu

Touch [Exit].

### Pandora® Operation

You can listen to the Pandora® on this unit by controlling the application installed in the iPhone or Bluetooth device.

To enter Pandora mode, touch [Pandora] icon in the Top Menu screen.

#### NOTE

- Install the latest version of the Pandora® application on your iPhone, Android or BlackBerry.
   iPhone: Search for "Pandora" in the Apple App Store to find and install the most current version.
   Android: Visit the Google play and search for Pandora to install.
   BlackBerry: Visit www.pandora.com from the built in browser to download the Pandora application.
- When you first select Pandora as a source, the setting screen for the connection with the device installed the apps will appear. For the details, refer to Application link setup (P.56).



### 1 Information display

Displays text information of current contents that is being played.

### 2 Artwork/Control switching area

The picture data is displayed if available from current content. Touch to switch between the Simple Control and List Control screen.

### 3 Multi function key

Touch to switch the multi function menu. For details on the menu, see Multi function menu (P.44).

### 4 Multi function menu

Various functions can be performed by using the keys in this area. For details on the keys, see <u>Multifunction menu</u> (P.44).

### 5 Sub function key

Touch to display "Sub function menu" (7 in this table).

### 6 Content information

Displays the information of the current content being played.

#### 7 Sub function menu

Various functions can be performed by using keys in this area. For details on the keys, see <u>Sub function</u> menu (P.44).

### 8 List switching key

Touch to switch between the content list and the current content information.

### CD/Audio and Visual Files/iPod/App Operation





The following functions can be performed by using keys in this area.



Searches for a station. For details on searching, see **Station list screen (P.45)**.

### [ ] (Thumbs down)

Thumbs down to the current song and skip to the next song.

### [►II]

Plays or pauses the content of the current station.

### [▶▶|]

Skips the current song.

(Note this function is disabled when the Pandora skip limitation is exceeded.)

### [ ] (Thumbs up)

Registers the current contents as favorite

### [ ] (Bookmark Artist)

Bookmark an artist in the current contents.

### [ ] (Bookmark Song)

Bookmark a song in the current contents.

### NOTE

• [SETUP], [AUDIO], and [REAR] functions same as iPod.

# Sub function menu



The following functions can be performed by using keys in this area.

### Status bar in center

Displays the elapsed time since when you select the station and status bar which shows current location.



Creates a new station based on an artist being played.



Creates a new station based on a song being played.



Displays the genre list screen. For details on searching, see *Genre list screen (P.45)*.

# Station list screen

You can perform the following functions from this screen.



### Selects the station

Touch the station name in the list.

### Sort the list in alphabetical order

You can select the desired letter from the list which corresponds to the station name to help narrow the search.

### Sort the list by registered date

Touch [ByDate]. The list is sorted to begin with the last registered station.

### NOTE

- You can operate Pandora by using the remote control. However, only playing, pausing, and skipping are available.
- You cannot select iPod as rear source when you select Pandora as main source in dual zone function.

## Genre list screen

You can perform the following functions from this screen.



The selected genre is created as a new station.

### iHeartRadio Operation

You can listen to the iHeartRadio on this unit by controlling the application installed in the iPhone or Android.

To enter iHeartRadio mode, touch [iHeartRadio] icon in the Top Menu screen.

#### NOTE

- Install the latest version of the iHeartRadio application "iHeartAuto" on your iPhone or Android.
   iPhone: Search for "iHeartAuto" in the Apple App Store to find and install the most current version.
   Android: Search for "iHeartAuto" in Google play to find and install the most current version.
- When you first select iHeartRadio as a source, the setting screen for the connection with the device installed the apps will appear. For the details, refer to *Application link setup (P.56)*.



### 1 Artwork switching area

The picture data is displayed if available from current content. When the picture is not available, "No Photo" is displayed.

### 2 Multi function key

Touch to switch the multi function menu. For details on the menu, see Multi function menu (P.47).

### 3 Multi function menu

Various functions can be performed by using the keys in this area. For details on the keys, see <u>Multifunction menu (P.47)</u>.

### 4 Sub function menu

The following functions can be performed by using keys in this area.

- Thumbs up to the current song: Touch [ ].
- Thumbs down to the current song. : Touch [ ].

### 5 Content information

Displays the information of the current content being played.

# Multi function menu



The following functions can be performed by using keys in this area.



Stops or pauses. (Live station only)

### [►II]

Plays or pauses. (Custom station only)

### [ **▶**▶| ]

Skips the current song. (Custom station only)

### [SCAN]

Scans for another station of the same genre. (Live station only)



Creates a custom station based on the current song.



Searches for a station. For details on searching, see **Station search** (P.47).



Saves currently playing station to My Stations. (Live station only)



Use the Discovery Tuner to set the variety level of a station. For details, see *Discovery tuner* (*P.48*). (Custom station only)

### NOTE

• [SETUP], [AUDIO], and [REAR] functions same as iPod.

# Station search

You can list and select station.

1 Touch [ ] in the control screen. The Station Search screen appears.



### Selects the category and station

Touch the category and station name in the list.

### [ [ ]

Returns to the first hierarchy of the category list

### [ 1

Returns to the previous category list.



Deletes a saved station from My Stations. For details, see *My stations edit (P.48)*.

### My stations edit

1 Touch [ in the Station Search screen.

Station Edit screen appears.

2 Select the station to delete from My stations.



### Selects the station

Touch to check the station name you want to delete.

You can uncheck if you touch it again.



Returns to the first hierarchy of the category list.



Returns to the previous category list.

- 3 Touch [ ]].
  Station Delete screen appears.
- 4 Touch [Yes].



My station selected is deleted.

# Discovery tuner

You can set the variety level in a custom station.

1 Touch [ in the control screen.
The Discovery tuner select screen appears.



### Selects the variety

Touch the variety you want to set.

### **AUPEO! Operation**

You can listen to the AUPEO! on this unit by controlling the application installed in the iPhone or Android.

To enter AUPEO! mode, touch [AUPEO!] icon in the Top Menu screen.

#### NOTE

- Install the latest version of the AUPEO! application "AUPEO!" on your iPhone or Android.
   iPhone: Search for "AUPEO!" in the Apple App Store to find and install the most current version.
   Android: Search for "AUPEO!" in Google play to find and install the most current version.
- When you first select AUPEO! as a source, the setting screen for the connection with the device installed the apps will appear. For the details, refer to *Application link setup (P.56*).



### 1 Artwork switching area

The picture data is displayed if available from current content. When the picture is not available, "No Photo" is displayed.

### 2 Multi function key

Touch to switch the multi function menu. For details on the menu, see Multi function menu (P.50).

### 3 Multi function menu

Various functions can be performed by using the keys in this area. For details on the keys, see <u>Multifunction menu (P.50)</u>.

### 4 Content information

Displays the information of the current content being played.





The following functions can be performed by using keys in this area.



Searches for a station. For details on searching, see **Station search** (**P.50**).



Touching the key "Love" current song.

[►II]

Plays or pauses.



Skips the current song.



Touching the key "Ban" current song.


### **NOTE**

• [SETUP], [AUDIO], and [REAR] functions same as iPod.



You can list and select station.

1 Touch [ ] in the control screen. The Station Search screen appears.



### Selects the category and station

Touch the category and station name in the list.



Returns to the previous category list.

### **Apps Operation**


You can listen to music or watch video from the Apps operating on iPod touch/iPhone or Android. To enter Apps mode, touch [APPS] icon in the Top Menu screen.

#### NOTE

• When you turn on the power and select apps as the source, the caution for the operation, watching video and listening music appears. With your acceptance, you can control apps, listen to music and watch video from apps when you are driving.



- When you first select APPS as a source, the setting screen for the connection with the device installed the apps will appear. For the details, refer to *Application link setup (P.56*).
- If the conditions below are satisfied, the touch keys will not appear, but the touch operation from the screen of the unit to the Android device becomes possible.
  - –The unit and the Android device are connected with KCA-MH100 (sold separately) and over Bluetooth profile HID and SPP.
  - -"Kenwood Smartphone Control" is installed on the Android device. For details, see web site. <a href="http://www.kenwood.com/products/car\_audio/app/kenwood\_smartphone\_control/eng/index.html">http://www.kenwood.com/products/car\_audio/app/kenwood\_smartphone\_control/eng/index.html</a>
- Depending on the app, the touch keys may not work or be displayed.



### 1 Multi function key (iPod touch/iPhone only)

Touch to switch the multi function menu.

### 2 Multi function menu (iPod touch/iPhone only)

The following functions can be performed by using keys in this area.

- Plays or pauses: Touch [▶], [Ⅱ], or [▶Ⅱ] (iPod only).
- Searches the previous/next track/file: Touch [I◄◄] or [▶►I]. [SETUP], [AUDIO], and [REAR] functions same as iPod.

### 3 Sub function menu (iPod touch/iPhone only)

The following functions can be performed by using keys in this area.

• Hides all keys (During video file playback only): Touch [ [ ]]


## **USB/iPod/App Setup**

You can perform setup when using USB/ iPod/ App.

### NOTE

- Each operation in this section can be started from the Top Menu screen. For details, see <u>Operating</u> with the Top Menu Screen (P.12).
- Some setup items can only be set in standby mode.
- 1 Touch [ ] in the control screen.

  Multi function menu appears.
- 2 Touch [SETUP].
  SETUP Menu screen appears.
- 3 Touch [Source].



Source SETUP Menu screen appears.

# 4 Touch [USB SETUP], [iPod SETUP], or [APP SETUP] in the list.

Each setup screen appears.
See the following section for each setting.

- USB setup (P.53)
- iPod setup (P.54)
- Application link setup (P.56)

# USB setup

### 1 Set each item as follows.



### **Picture Display Time**

Selects length of time to display JPEG picture file in the screen. Select from [Short], [Middle], and [Long] (default).

### On Screen USB

Sets how to display the information of the USB device.

**Auto (Default)**: Information appears for 5 seconds when updated.

OFF: Does not display any information.



### 1 Set each item as follows.



### AudioBook Speed

Sets the audio book playback speed. Select from [Slow]. [Normal] (default), and [Fast].

#### Wide Screen\*

Sets Wide Screen. Set [ON] (default) or [OFF].

### On Screen iPod

Sets how to display the information of the iPod.

**Auto (Default)**: Information appears for 5 seconds when updated.

OFF: Does not display any information.

### iPod connection setup

Sets the way to connect the iPod/iPhone with this unit For details on searching, see <u>iPod/iPhone connection setup (P.54)</u>.

\* This setting is not available when an iPod is connected.

### iPod/iPhone connection setup

# 1 Touch [iPod Connection Setup] in the iPod Settings screen.

iPod connection setup screen appears.

### 2 Touch [CHANGE].



### 3 Select the way to connect the iPod/ iPhone with this unit.



### USB + AV-IN

Select when connecting with KCA-iP202.

### **USB 1Wire**

Select when connecting with KCA-iP103 or KCA-iP102.

#### HDMI + BT

Select when connecting with KCA-HD100 and Lightning Digital AV Adapter.

### **Bluetooth**

Select when connecting via Bluetooth only.

### 4 Touch [Next].

Confirmation screen appears.

### 5 Touch [Done].

### NOTE

- For the details of the necessary cable and adapter to connect with iPod/iPhone, refer to <u>Music/</u> <u>Video/Picture Basic Operation (P.30)</u>.
- When you select "HDMI + BT" or "Bluetooth" in step 3, Bluetooth device selection screen will appear. Select the iPod/iPhone to be connected.



If a connectable Bluetooth device is not displayed, touch [Search] and do the pairing of the devices.

# Application link setup

Sets the device an application is installed in and the app is selected as the source.

### 1 Touch [CHANGE].



### 2 Select the device installed the apps.



### iPod / iPhone

Select when using iPod/iPhone.

### Android / Other

Select when using Android or BlackBerry device.

### 3 Touch [Next].

Connection setup screen appears.

# 4 Select the way to connect the device with this unit.



### When selecting [iPod / iPhone]

### USB + AV-IN

Select when connecting with KCA-iP202.

### **USB 1Wire**

Select when connecting with KCA-iP103 or KCA-iP102.

#### HDMI + BT

Select when connecting with KCA-HD100 and Lightning Digital AV Adapter.

### Bluetooth

Select when connecting via Bluetooth only.

### When selecting [Android / Other]

### HDMI/MHL + BT

Select when connecting with KCA-MH100.

### Bluetooth

Select when connecting via Bluetooth only.

### 5 Touch [Next].

Confirmation screen appears.

### 6 Touch [Done].

#### NOTE

- This setup can be set when in STANDBY source.
- To enable the touch operation on this unit, install "Kenwood Smartphone Control" and start it.
   Search for "Kenwood Smartphone Control" in Google play to find and install the most current version.
- When you select APPS source and APP Settings appears, touch [OK] after setting.
   The screen will return to APP after you agree the caution.



- For the details of the necessary cable and adapter to connect with iPod/iPhone and Android, refer to Music/Video/Picture Basic Operation (P.30).
- When you select "HDMI + BT","HDMI/MHL + BT" or "Bluetooth" in step 4, Bluetooth device selection screen will appear. Select the device to be connected.



If a connectable Bluetooth device is not displayed, touch [Search] and do the pairing of the devices.

 When you select "iPod/ iPhone" in Apps Setup, select "iPod" as the source, and select App on the iPod, the source of this unit is also changed to App automatically.

# **H**D Radio<sup>™</sup> Tuner Operation

### **HD Radio Tuner Basic Operation**

Most functions can be controlled from the source control screen.

### NOTE

• Set the remote control mode switch to AUD mode before starting operation, see **Switching the operation mode (P.115)**.



### 1 PS/Station name display

Displays the PS name or station name.

### 2 Information display/Control switching area

Displays the following information.

- Picture: The picture data or station Logo data is displayed if available from current content.
- [FM1] etc.: Band display
- · MHz/kHz: Frequency display
- Preset #: Preset number
- HD#: Channel display

Touch to switch between the Simple Control and List Control screen.

### 3 Multi function key

Touch to switch the multi function menu. For details on the menu, see Multi function menu (P.59).

### 4 Preset key/Multi function menu

Recalls the memorized station or channel. When touched for 2 seconds, stores the current receiving station or channel in memory.

When switched, various functions can be performed by using keys in this area.

For details on the menu, see Multi function menu (P.59).

### 5 Sub function key

Touch to display "Sub function menu" (7 in this table).

#### 6 Preset list

Displays the list of preset stations or channels and the information.

### 7 Sub function menu

The following functions can be performed by using keys in this area.

- Switches the band: Touch [AM] or [FM].
- Tunes in a station: Touch [◄◄] [►►]. The method of frequency switching can be changed. See <u>Multifunction menu (P.59)</u>.
- Selects a channel: Touch [CH▼] or [CH▲].
- Stores the information about the song being received: Touch [ ] . See **Bookmark** (P.65).
- Tunes in by entering direct number:

Touch [ ] and enter the desired number. For details, see *Direct search (P.63)*.

### 8 List switching key

Touch to switch between the preset list and the information list.

Tuned program information will be displayed.

## Multi fu

### Multi function menu



The functions of each key are as follows.

### [P1] - [P6]

Selects the preset station. Touch for 2 seconds to store the current station into the preset memory.



Selects the method of searching from preset stations selecting or channel searching. For details on search operation, see *Selecting Operation (P.62)*.

#### [TI]

Sets the traffic information mode on. For details, see *Traffic Information (P.64)*.

### [SEEK]

Switches the seek mode in the following sequence; [AUTO1], [AUTO2], [MANUAL].

- AUTO1: Tunes in a station with good reception automatically.
- AUTO2: Tunes in stations in memory one after another.
- MANUAL: Switches to the next frequency manually.

### [AME]

Selects the auto memory mode. For details, see *Auto memory (P.61)*.

### [PTY]

Searches a program by setting program type. For details, see Search by program type (P.62).

#### [RCV]

Switches the receive mode in the following sequence; [AUTO], [DIGITAL], [ANALOG]. For details, see *Receive Mode (P.64)*.

### [ 🔧 SETUP]

Touch to display the SETUP Menu screen. See Setting Up (P.92).

### [ AUDIO]

Touch to display the Audio Control screen. See **Controlling Audio (P.104)**.

Continued

### [REAR 🖎]

Touch to mute the rear speaker.



This HD Radio receiver enables:

**PSD** 

HD2/HD3

Bookmark

**Digital Sound** 

**Artist Experience** 

# PSD)

• Program Service Data provides song name, artist, station ID, and other relevant data streams

## HD2/HD3

 Adjacent to traditional main stations are HD2/HD3 Channels, providing new original formats on the FM dial

# Bookmark

 Bookmark is a music & product discovery feature that enables users to store information about content on the radio and delivers interactive information via OR codes

# Digital Sound

 HD Radio broadcasts deliver crystal clear, CD-like digital audio quality to consumers

# Artist Experience

 Visual images, such as album art of over-the-air broadcasts from HD Radio stations

### **Memory Operation**



### Auto memory

You can store stations with good reception in memory automatically.

### NOTE

- Auto memory terminates when 6 stations are stored or when all stations are tuned in.
- The operation ends automatically if you do not operate within 10 seconds.
- 1 Touch [ ].
  Sub function menu appears.
- 2 Touch desired band key.



- 3 Touch [ 1 in the control screen. The multi function menu appears.
- 4 Touch [AME] in the multi function menu.
- 5 Touch [◄◄] or [►►] in the sub function menu.

Auto memory starts.

# Manual memory

You can store the current receiving station or channel in memory.

- Select a station or channel you wish to store in memory.
- 2 Touch [P#] (#:1-6) in which you want to store the station or channel for 2 seconds until a beep sounds.

### **Selecting Operation**



### **Preset select**

You can list and select memorized station or channel.

### Selecting from the multi function menu

1 Touch the desired number from P1 to P6.

The unit will tune to the selected station or channel.

### Selecting from the preset list

Touch illustrated area.



List Control screen appears.

### 2 Select a station or channel from the list.

### NOTE

# Search by program type

You can tune to a station with a specific program type when listening to FM.

- 1 Touch [ ] in the control screen.
  The multi function menu appears.
- **2** Touch [PTY] in the multi function menu. TUNER PTY Mode screen appears.
- 3 Select a program type from the list.
- 4 Touch [Search].



You can search a station of the selected program type.

## Direct search

You can tune in by entering the desired frequency or channel number.

### 1 Touch illustrated area.



List Control screen appears.

### 2 Touch [ ].



10Key Direct screen appears.

# 3 Enter the channel number and touch [Enter].

### NOTE

- To cancel the direct search, touch [Cancel].
- To clear the number you entered, touch [Clear].
- You can search by frequency. Each time you touch [Mode] in the left part of the screen, it changes the mode between frequency entering mode and channel entering mode.

## Category/Channel search

You can specify the desired category and select a channel.

- 1 Touch [ ] in the control screen.
  The multi function menu appears.
- 2 Touch [ a ] in the multi function menu. List select screen appears.
- 3 Touch [Preset list] or [Category/ Channel list].



The previously used category or channel list appears.

### 4 Select the desired content from the list.

#### NOTE

• Each time you touch [Info Change] in the channel list, switches the sequence of the list.

Song title, artist name, album name

### **Traffic Information**

You can listen and watch the traffic information automatically when a traffic bulletin starts.

However, this feature requires a Radio Broadcast Data System that includes the TI information.

- 1 Touch [ ] in the control screen.
  The multi function menu appears.
- **2** Touch [TI] in the multi function menu. Traffic information mode is set.

# When the traffic bulletin starts

The Traffic Information screen appears automatically.



#### NOTE

- It is necessary to have Traffic Information function set to on in order to have the Traffic Information screen appear automatically.
- The volume setting during reception of traffic information is automatically stored. The next time the traffic information is received, this unit recalls the volume setting automatically.

### **Receive Mode**

You can set the radio broadcasts receive mode.

- 1 Touch [ ] in the control screen.
  The multi function menu appears.
- **2** Touch [RCV] in the multi function menu. HD Radio tuner Mode screen appears.
- 3 Select the receive mode from [Auto], [Digital], and [Analog] using [◄] and [►].



#### NOTE

• If you select [Auto], tunes to analog broadcast automatically when there is no digital broadcast.

### **Bookmark**

Stores tag information (title, artist, album, URL, and description) about the song you are listening to now.

Detailed information and QR codes can be displayed according to the stored tag information.



### Registering a bookmark

- 1 Touch [ ].
  Sub function menu appears.
- 2 Touch [ ] ].
  Registers a bookmark.

### **NOTE**

• Up to 100 bookmarks can be registered to this

## **Bookmark list**

Displaying a list of registered bookmarks and detailed information and QR code of the song.

- 1 Touch [ ] in the control screen.
  The multi function menu appears.
- 2 Touch [ ] in the multi function menu. List select screen appears.
- 3 Touch [Bookmark].



The Bookmark List appears.

4 Select the desired bookmark from the list.



The bookmark information appears.





Deletes the bookmarks being displayed.

## **Bookmark delete**

Deleting a bookmark.

- 1 Touch [ ] in the control screen.
  The multi function menu appears.
- 2 Touch [ ] in the multi function menu. List select screen appears.
- 3 Touch [Bookmark].



The Bookmark List appears.

4 Touch [Delete List].



The Bookmark Delete List appears.

5 Select the bookmark to delete from the list.



[AII]

Select all bookmarks.

6 Touch [ 📸 ].

Deletes all the selected bookmark(s)

# SiriusXM® Operation

### SiriusXM® Basic Operation

Most functions can be controlled from the source control screen.

#### Before use

- SiriusXM® Satellite Radio operation requires the connection of the optional SiriusXM Connect Vehicle Tuner and service. To activate the SiriusXM Connect Vehicle Tuner, you will need the Radio ID.
- Make a note of your Radio ID: For each SiriusXM Connect Vehicle Tuner, peculiar Radio ID is assigned. To confirm your Radio ID, tune to channel 0. The letters I, O, S and F are not used in any Radio ID.

  The Radio ID is also located on the label of the SiriusXM Connect Vehicle Tuner.
- How to activate your SiriusXM Service: Go to www.siriusxm.com/activatenow or call 1-866-635-2349 to activate your SiriusXM Vehicle Connect Tuner.

To activate SiriusXM Canada service go to www.xmradio.ca and click on "ACTIVATE RADIO" in the top right corner, or call 1-877-438-9677

### NOTE

- Set the remote control mode switch to AUD mode before starting operation, see **Switching the operation mode (P.115)**.
- To use SiriusXM® Satellite Radio, the optional accessory is necessary.



### 1 Signal Strength indication

Displays the received signal strength of the SiriusXM tuner.

### 2 Information display/Control switching area

Displays the following information.

• [SXM1], etc.: Band display • Preset #: Preset number

• #CH: Channel display

• Logo: Channel logo display

Touch to switch between the Simple Control and List Control screen.

### 3 Multi function key

Touch to switch the multi function menu. For details on the menu, see Multi function menu (P.69).

### 4 Preset key/Multi function menu

Recalls the memorized channel. When touched for 2 seconds, store the current receiving channel in memory.

When switched, various functions can be performed by using keys in this area.

For details on the menu, see Multi function menu (P.69).

### 5 Sub function key

Touch to display "Sub function menu" (7 in this table).

#### 6 Music information

Displays the information of the current channel: Channel Name, Artist Name, Song Title, Content Info, Category Name, Channel Description, Similar Channels

### 7 Sub function menu

The following functions can be performed by using keys in this area.

- Tunes in a station: Touch [CH▼] [CH▲].
- Searches the previous/next track: Touch [I◄◄] [▶►]. fast forward/fast backward when keep on touching. See *Replay (P.74*).
- Tunes in by entering direct number: Touch [ ] and enter the desired number. For details, see Direct search (P.72).

### 8 List switching key

Touch to switch between the preset list and the information list.



### Multi function menu



The functions of each key are as follows.

### [P1] - [P6]

Selects the preset channel. Touch for 2 seconds to store the current station into the preset memory.



Selects the method of searching from preset channel selecting or category/channel searching. For details on search operation, see *Selecting Operation (P.71)*.

### [SEEK]

Switches the seek mode in the following sequence; [SEEK1], [SEEK2].

- SEEK1: Tunes channels one after the other.
- SEEK2: Selects channels in preset (memory) one after the other.

### [BAND]

Switches the band.

### [**▶**II]

Plays or pauses. See Replay (P.74).



Touch for 2 seconds to register content as Alert content.

- [ ]: Registers the artist of the song you are listening to now as an alert content.
- [ ]: Registers the song you are listening to now as an alert content.

For details, see Content alert (P.73).

Continued

### Return to the Top page SiriusXM Operation



Turns the Traffic & Weather Jump function on or off.

For details, see City select for Traffic & Weather Jump (P.79).



Listen to live.

### [TuneScan]

Hear a few seconds of the songs from each of the SmartFavorite music channels on the current preset band. See  $TuneScan^{TM}$  (P.75).



Touch to display the SETUP Menu screen. See Setting Up (P.92).



Touch to display the Audio Control screen. See Controlling Audio (P.104).

### [REAR 💌]

Touch to mute the rear speaker.

### **Memory Operation**



### Manual memory

You can store the current receiving station or channel in memory.

- 1 Select a station or channel you wish to store in memory.
- 2 Touch [P#] (#:1-6) in which you want to store the station or channel for 2 seconds until a beep sounds.

### **Selecting Operation**



### Preset select

You can list and select memorized station or channel.

### Selecting from the multi function menu

1 Touch the desired number from P1 to P6.

The unit will tune to the selected station or channel.

### Selecting from the preset list

1 Touch illustrated area.



List Control screen appears.

2 Select a station or channel from the list.

### NOTE

## Direct search

You can tune in by entering the desired frequency or channel number.

#### 1 Touch illustrated area.



List Control screen appears.

### 2 Touch [ ]].



10Key Direct screen appears.

## 3 Enter the channel number and touch [Enter].

#### NOTE

- To cancel the direct search, touch [Cancel].
- To clear the number you entered, touch [Clear].

## Category/Channel search

You can specify the desired category and select a channel.

- 1 Touch [ ] in the control screen.
  The multi function menu appears.
- 2 Touch [ ] in the multi function menu. List select screen appears.
- 3 Touch [Category/ Channel list].



The previously used category or channel list appears.

#### 4 Select the desired content from the list.

#### NOTE

- · All the channels in the selected category appear.
- Touching [All Channel] displays all the channels.
- Each time you touch [Info Change] in the channel list, switches the sequence of the list.

Channel name, artist name, song title, category name, content info

### **Content alert**

When a broadcast program related to the registered artist, song or team starts, a message appears to allow you to switch the current channel to the relevant channel.

1 When the broadcast of the registered content starts, an Alert screen appears.



#### Jump

Touch to display the Alert Content List screen.

#### Ignore

Touch to cancel the Content alert.

#### 2 Select a content from the list.




- Each time you touched [Type], switches the sequence of the Content alert list as follows; Artist Alert, Song Alert, GameAlert™
- For how to register artists and songs and turn on/ off the Team alert function, see <u>Multi function</u> menu (P.69).
- For how to set up the Content alert function, see *SiriusXM Setup (P.76)*.

### Replay

You can replay last 60 minutes of current channel.

### 1 Touch [SiriusXM] in the Top Menu.



#### 

Searches the previous/next track. Fast forward/fast backward when keep on touching.

#### [**►**II]

Plays or pauses.

#### [CH▼] [CH▲]

Tunes in a station.

#### Replay time bar

Display recorded capacity and playback position.



Listen to live.



Displays a list of recorded data on a program basis.

#### [BAND]

Switches the band.

### 2 Touch [ ] to display a program list.



#### **Program list**

Touching this plays back the displayed program.

#### [Info Change]

Touching this allows you to switch among the Artist name, Song title, Category name, and Content info cyclically.

### **Smart Favorites, TuneStart™**

Station memory number 1 though 6 of current band are Smart Favorite channels. SiriusXM Vehicle Tuner automatically buffered the broadcast audio content of the Smart Favorites channels in the background.

You can rewind and replay up to 30 minutes of any of the missed news, talk, sports or music content when you tune to a Smart Favorite channel. (see *Replay (P.74*))

When tuning Smart Favorites channels, songs will play from the beginning of each track (Tune Start). You can enable/disable Tune Start. (see *TuneStart™ (P.80)*)

### TuneScan™

TuneScan™ is a feature that plays samples from the starts of multiple buffered songs from each of the Smart Favorite channels that predominantly play music selections. You have easy access to a large sampling of music content and can enjoy hearing a full song when stopping the scan on a song of interest.

- 1 Touch [ ] in the control screen.
  The multi function menu appears.
- 2 Touch [TuneScan] in the multi function menu.

The introductions of the songs will be played in recorded order.

3 Touch [TuneScan] while your favorite song is being played.



Scan finishes and continues playing the song.

#### NOTE

To cancel Tune Scan, Touch [TuneScan] for 2 seconds.

After cancel, the channel before starting Tune Scan will be played.

### SiriusXM Setup

#### NOTE

- Each operation in this section can be started from the Top Menu screen. For details, see <u>Operating</u> with the Top Menu Screen (P.12).
- 1 Touch [ ] in the control screen.

  Multi function menu appears.
- 2 Touch [SETUP] in the multi function menu.

SETUP Menu screen appears.

3 Touch [Source].



Source SETUP Menu screen appears.

4 Touch [SiriusXM SETUP] in the list.

Sirius XM SETUP screen appears.
See the following section for each setting.

- Set up the parental code (P.76)
- Set up the parental control (P.77)
- Set up the skip channel select (P.78)
- Set up the Content alerts (P.78)
- Set up the content for Content alerts (P.79)
- Select the city for Content alerts (P.79)
- Set up the TuneStart™ (P.80)
- Reset to the default settings (P.80)

## Parental code

You can set a SiriusXM parental code.

1 Touch [Change] of [Parental Code] in the SiriusXM SETUP screen.

Parental Pass Check screen appears.

#### NOTE

- The code number is set to "0000" as default.
- **2** Enter the current code number.
  Parental Pass 1st entering screen appears.
- 3 Enter the new code number and touch [Enter].

Parental Pass 2nd entering screen appears.

4 Enter the same code number as you input in step 3 and touch [Enter].

The code number is confirmed and SiriusXM parental code is now set.

## Parental control

Parental control is a feature that provides the user with the ability to prevent unauthorized access to mature content and user selected channels.

- 1 Touch [ON] or [OFF] of [Parental Lock Mature] in the SiriusXM SETUP screen.
- 2 Enter the same code number as you originally input in <u>Parental code (P.76)</u> and touch [Enter].

Turns the Mature on or off.

Default is "OFF".

If you want to separately set the parental lock for each channel, select OFF and proceed to step 3 onward.

3 Touch [SET] of [Parental Lock Channel Select] in the SiriusXM SETUP screen.

Parental Pass Check screen appears.

#### NOTE

- You need to complete <u>Parental code (P.76)</u> beforehand.
- To delete the parental lock channel setting, touch and hold [Unlock All] for 2 seconds, enter the Parental code number, then touch [Enter].
- 4 Enter the same code number as you originally input in <u>Parental code (P.76)</u> and touch [Enter].

Parental Lock Category Select screen appears.

5 Touch the desired category from the list.



Displays all the channels in the selected category.

#### NOTE

• Touch [All Channels] to display all the channels.

## 6 Touch each channel list and set on or off.



- Each time you touched [Info Change], switches the sequence of the channel list as follows; Channel name, Artist name, Song title, Category name, Content information.
- Touch [1] to return to Parental Lock Category Select screen.
- Touch [ ] to return to SiriusXM SETUP screen.

## Skip channel select

You can set the undesired channels to skip.

- 1 Touch [SET] of [Skip Channel Select].
  Skip Category Select screen appears.
- 2 Touch the desired category from the list.

Displays all the channels in the selected category.

3 Touch each channel list and set ON or OFF.

#### NOTE

- Operations in each list screen are same as *Parental control (P.77)*.
- To delete the skip channel setting, touch and hold [Unskip All] for 2 seconds.

## Content alerts setup

You can turn on or off the Content alerts function.

1 Touch [ON] or [OFF] of [Content alerts] in the SiriusXM SETUP screen.

Turns the Content alerts on or off. Default is "ON".

## Content alerts Contents Set

You can set a content for Content alerts.

1 Touch [SET] of [Content alerts Contents Set] in the SiriusXM SETUP screen.

Artist list screen appears.

#### NOTE

• To set all the content alerts off, touch and hold [Disable All] for 2 seconds.



2 Touch [Type] to select the screen of the content you want to set up.

Touching this allows you to switch among the Artist list, Song list, and Team list cyclically.

3 Touch each content list and set ON or OFF.

#### NOTE

- Touch "Delete" to delete the currently selected content from the Artist list and Song list.
- Available teams were pre-registered in the Team list. Team(s) cannot be registered or deleted manually.

# City select for Traffic & Weather Jump

You can select a city for which traffic information or weather forecast is to be received with the Content alerts function.

1 Touch [◄] and [►] of [Traffic Weather Jump City Select] to select a city.



1 Touch [ON] or [OFF] of [Tune Start] in the SiriusXM SETUP screen.

Turns the Tune start on or off. Default is "ON".



1 Touch [Reset] of [SiriusXM Reset] for 2 seconds in the SiriusXM SETUP screen.

All SiriusXM setting returns to default.

## **Bluetooth Control**

Using the Bluetooth function, various functions can be used: listening to the audio file, making/receiving a call.



# About the cell-phone and Bluetooth audio player

This unit conforms to the following Bluetooth specifications:

#### Version

Bluetooth Ver. 3.0+EDR Certified

#### **Profile**

#### Cell-phone:

HFP (V1.6) (Hands Free Profile)

SPP (Serial Port Profile)

SDP (Service Discovery Profile)

PBAP (Phonebook Access Profile)

GAP (Generic Access Profile)

#### Audio player:

A2DP (Advanced Audio Distribution Profile) AVRCP (V1.4) (Audio/Video Remote Control Profile)

#### Sound codec

SBC, AAC, MP3

#### NOTE

• For the cell-phones verified for compatibility, access the following URL:

http://www.kenwood.com/cs/ce/bt/

 The units supporting the Bluetooth function have been certified for conformity with the Bluetooth Standard following the procedure prescribed by Bluetooth SIG.

However, it may be impossible for such units to communicate with your cell-phone depending on its type.

# Registering And Connecting Bluetooth Unit

It is necessary to register the Bluetooth audio player or cell-phone to this unit before using the Bluetooth function.

You can register up to 5 Bluetooth units.

- 1 Touch [Menu] on any screen.
- **2 Touch [SETUP].**SETUP Menu screen appears.
- 3 Touch [Bluetooth].



Bluetooth SETUP screen appears.
See the following section for each setting.

- Registering the Bluetooth Unit (P.83)
- Connecting the Bluetooth unit (P.83)

## Registering the Bluetooth Unit

#### 1 Touch [Search].

Searched Device List screen appears.

#### NOTE

 You cannot register the Bluetooth unit when you are using the following sources: iPod, Bluetooth Audio, APPS, iHeart, Pandora,

iPod, Bluetooth Audio, APPS, iHeart, Pandora, AUPFO!

If you want to register the Bluetooth unit while using one of the above mentioned sources, send the connection request from the Bluetooth unit and register it.

- A new device cannot be registered if there are 5 registered Bluetooth units. Delete unnecessary registration. See <u>Connecting the Bluetooth unit</u> (P.83).
- This unit is compatible with the Apple Easy Pairing function. When an iPod touch or iPhone is connected to this unit, an authentication dialog appears. Performing operation for authentication on this unit or iOS smartphone registers the smartphone as a Bluetooth device.
- If two Bluetooth units are connected, this unit will not start the search. In this case disconnect one of the Bluetooth units.

## 2 Select the Bluetooth unit to register from the list.



#### NOTE

- If the unit cannot be searched in step 1, you can search the unit again by touching [Search] in above screen.
- Touch [Cancel] to cancel searching for the Bluetooth unit.

### 3 Enter PIN code form the cell-phone.

Profile select screen appears.

## Connecting the Bluetooth unit

## 1 Touch the device name you want to connect.

Profile select screen appears.

#### NOTE

• If the icon is lighted, it means that the unit will use that device.

#### 2 Set each profile as follows.



#### TEL (HFP)

Means that the device is a cell-phone.

#### Audio (A2DP)

Means that the device is an audio player or cell-phone with audio player.

- If a device has been paired, the Bluetooth unit cannot be connected from the paired device.
- Touching [Remove] of [Device Remove Confirm] removes registration information. After you touch the key, a confirmation message appears. Follow the message and complete the operation.

### **Playing Bluetooth Audio Device**

## Bluetooth basic operation



#### 1 Information display

Displays the name of the track information. If the information is not available, device name is displayed.

#### 2 Multi function key

Touch to switch the multi function menu.

#### 3 Multi function menu

The functions of each key are as follows.

- [I◄◄] [▶►I]: Searches the previous/next content.\*
- [▶]: Plays.\*
- [II]: Pauses.\*
- [■]: Stops playback.\*
- [ AUDIO]: Touch to display the Audio Control screen. See **Registering the Bluetooth Unit** (P.83).
- [ SETUP]: Touch to display the SETUP Menu screen. See Setting Up (P.92).
- [ REAR 🗱 ]: Touch to mute the rear speaker.

#### 4 Control switching area

Touch to switch between the Simple Control and List Control screen.

#### 5 File information

Displays the information of the current file.

#### 6 Status bar

Displays the current play location, play time, and play mode.

#### \* These items appear only when the audio player which supports AVRCP profile is connected.

- If the operation keys do not appear, operate from the player.
- Depending on your cell-phone or audio player, audio may be heard and controlled but text information may not appear.
- If the volume is too low, raise it on your cell-phone or audio player.

### **Using Hands-Free Unit**

You can use telephone function by connecting the Bluetooth telephone to this unit.



### Making a call

#### 1 Press the <TEL> button.



#### Hands Free screen appears.

#### NOTE

- When registration of your cell-phone is completed, the phone book of the cell-phone is automatically downloaded to this unit.
- Up to 600 phone numbers can be registered for each registered cell-phone.
- Up to 30 digits can be registered for each phone number along with up to 50 characters representing a name. (50 is the number of alphabetical characters. Fewer characters can be input depending on the type of characters.)
- Depending on the type of your cell-phone, the following restrictions are placed;
- The phonebook data cannot be downloaded normally.
- · Characters in the phonebook are garbled.
- To cancel downloading the phonebook data, operate the cell-phone.

### 2 Select a dialing method.



See the following table for each method.

#### Select the cell-phone to use

1) Touch [ 2 Android shone ] (cell-phone name display).

#### Call by entering a phone number

- ①Touch [##].
- ②Enter a phone number with number keys.
- ③Touch [ 📞 ].

#### Call using call records

- ①Touch [ 📞 ], [ 💟 ], or [ 📞 ].
- 2) Select the phone number from the list.
- ③Touch [ ].

#### Call using the phonebook

- ①Touch [ 🧾 ].
- ② Select the name from the list.\*1\*2
- 3 Select the number from the list.
- 4 Touch [ ].

#### Call using the preset number

- ① Touch [Preset #] to start calling the corresponding phone number.
- ②Touch [ 📞 ].

#### **Bluetooth SETUP**

① Touch [ ].
Bluetooth SETUP screen appears.

#### When you connect two cell-phones

Touch [ Android phone ] to select the phone you want to use.

\*1 You can sort the list to begin with touched character.



- Characters with no corresponding name will not appear.
- During search, a non-accent character such as "u" is searched for instead of an accent character such as "ü".
- \*2 You can set the list to arrange in the order of last name or first name. For details, see *Hands-Free Setup (P.90)*.

#### NOTE

- If you edited the phonebook in your cell-phone, touch "Download" on top of the phonebook list in this unit to download it from your cell-phone. The phonebook in this unit will be updated with the latest downloaded data.
- The status icons such as battery and antenna displayed may differ from those displayed on the cell-phone.
- Setting the cell-phone in the private mode can disable the hands-free function.

## Receiving a call

1 Touch [ ] to answer a phone call or [ ] to reject an incoming call.



#### NOTE

 While monitoring the camera view, this screen does not appear even if a call comes in. To display this screen, press the <TEL> button or return the shift knob of car to the driver position.

#### Operations during a call

#### Adjust the receiver volume

Turn the volume knob.



#### Output the dial tone

Touch [DTMF] to display the tone input screen. You can send tones by touching desired keys on the screen.

#### Switching the speaking voice output

Touching [ ( ) ] / [ ( ) ] ] each time switches the speaking voice output between cell-phone and speaker.

#### Call-waiting

When you receive a call while talking on another call, you can answer the newly received call by touching [ ]. The current call is on hold.

Each time you touch [ ], the caller will change.

When you touch [ ], the current call will end and switch to the call in hold.

## Phone number preset

You can register frequently used phone numbers to this unit.

1 Enter the number you want to register in Hands Free screen.




2 Touch [Preset 1], [Preset 2], or [Preset 3] for 2 seconds in the Hands Free screen.

## Voice Recognition

You can access the voice recognition function of the cell-phone connected to this unit. You can search the cell-phone phonebook by voice. (The functionality depends on the cell-phone.)

#### 1 Press the <TEL> button for 1second.



Voice Recognition screen appears.

#### 2 Start speaking.

#### NOTE

• You can use voice recognition function by touching [ ) on the Hands Free screen.

### **Smartphone Link**

When you install the Garmin Smartphone Link app into your Android smartphone and connect with the unit via Bluetooth SPP, you can use some information linked with the navigation such as parking lot, fuel price, live traffic camera, weather forecast and traffic condition.

#### Preparation

- Search for "Smartphone Link" in the Google play and install the latest version on your Android.
- 1 To enter STANDBY source, touch [STANDBY] icon in the Top Menu screen.
- 2 Register the Android smartphone. See *Application link setup (P.56)*.
- 3 Press the <NAV> button.



Navigation screen appears.

Touch [Apps] on the Main Menu screen and then touch an icon of your desired content. For details, see the Navigation system manual.

### **Hands-Free Setup**

You can perform various setup about handsfree function.

- 1 Touch [Menu] on any screen.
- **2 Touch [SETUP].**SETUP Menu screen appears.
- 3 Touch [Bluetooth].



Bluetooth SETUP screen appears.

4 Touch [TEL SETUP] in the Bluetooth SET-UP screen.



Hands-free SETUP screen appears.

#### 5 Set each item as follows.



#### **Bluetooth HF/Audio**

Select the speakers to output the sound from cell-phone (such as phone call voice and ringing tone) and Bluetooth audio player.

Front Only: Outputs from the front speakers.

All (Default): Outputs from all speakers.

#### **Auto Response\***

Sets an automatic response time to pick-up an incoming call.

**OFF (Default)**: Automatic response is not available.

0-99: Set calling ring time (second).

#### **Auto Pairing**

When set to "ON", the Apple Auto Pairing function is turned on to automatically register the iPod touch or iPhone connected to this unit.

**ON (Default)**: Uses Apple Auto Pairing function.

OFF: Not uses Apple Auto Pairing function.

#### **Phone Information Use**

Sets whether to use phonebook, outgoing, incoming and missed calls list.

ON (Default): Yes.

OFF: No.

#### **Sort Order**

Sets how to arrange the cell-phone phonebook.

First: Arranges in the order of first name.

**Last (Default):** Arranges in the order of last name.

#### **Echo Cancel Level**

Adjusts the level of echo cancellation. Default is "0".

#### Microphone Level

Adjusts the sensitivity of the telephone microphone. Default is "15".

#### **Noise Reduction Level**

Reduces the noises generated by surrounding environment without changing the microphone volume. Use this setting when the voice of caller is not clear. Default is "-10".

#### [Restore]

Resets the settings to the default settings.

\* Either the time interval for automatic answer set on this unit or the time interval set on the cell-phone, whichever is shorter takes effect.

## **S**etting Up

### **Monitor Screen Setup**

You can adjust image quality in iPod video, picture file, menu screen, etc.

## 1 Touch the lower left area of any screen for at least 1 second.



Screen Control screen appears.

### 2 Adjust each item as follows.

iPod/ AV-IN/ Camera



DVD/USB



# Bright / Tint\* / Color\* / Contrast / Black / Sharpness\*

Adjusts each item.

#### Dimmer

Select dimmer mode.

ON: The display and buttons dim.

OFF: The display and buttons do not dim.

SYNC (Default): Turns the dimmer function on or off when the vehicle light control switch is turned on or off

NAV-SYNC: Turns the dimmer function on or off according to the Navigation Day/Night display setting.

#### Mode\* (except USB)

Select screen mode.

Full: Full picture mode



Just: Justify picture mode



Zoom: Zoom picture mode



Normal: Normal picture mode




#### \* Playback screen only

- Adjusting items are different depending on the current source.
- You can perform this function only when you have applied the parking brake.
- The image quality can be set for each source.

### **System Setup**

#### NOTE

- Each operation in this section can be started from the multi function menu.
- 1 Touch [Menu] on any screen. TOP Menu screen appears.
- 2 Touch [SETUP].
- 3 Touch [System].



System Menu screen appears.
See the following section for each setting.

- Set up the user interface (P.94)
- Adjust touch panel (P.95)
- Set up securityl (P.96)
- Set up memory (P.96)

## **User interface**

You can setup user interface parameters.

- 1 Touch [User Interface] in the list.
  User Interface screen appears.
- 2 Set each item as follows.



#### Beep

Turns the key touch tone on or off. Default is "ON".

#### Language

Select the language used for the control screen and setting items. See <u>Language setup</u> (P.95).

#### **Text Scroll**

Allows scrolling of text display on the source control screen. Select from "Auto"/"Once"/"OFF".

Auto (Default): Scrolls the text automatically.

**Once**: Allows you to scroll the text only once automatically when updated.

OFF: Does not scroll the text automatically.

#### **Drawer Close**

Sets whether to close the common menu (P.14) automatically. Default is "Auto".



#### TEL Key Longer than 1 Second \*

You can set the operation performed when the TEL key is pressed for 1 second. Select from "Voice"/"V.OFF"/"R-CAM".

**Voice (Default)**: Displays the Voice Recognition screen. *(P.88)*.

V.OFF: Turn the display off.

R-CAM: Switches to the rear view camera video display.

#### **Animation**

Sets whether to display animation. Default is "ON".

#### Secondary

Sets whether to display the navigation information in the audio screen or vice versa. Default is "ON".

\* No audio is outputted from the rear view camera when selecting R-CAM by pressing TEL key for more than 1 second. The audio is outputted only when shifting a car into reverse. See *Camera Setup (P.100)*.

#### Language setup

1 Touch [SET] of [Language] in the User Interface screen.

Language Setting screen appears.

2 Set each item as follows.



#### Select Mode

Selects the mode to select a language.

Easy (Default): Selects a language easily.

**Advanced**: Allows you to select languages for respective items.\*

#### **Language Select**

Selects a language.

\* If you select [Advanced] for Select Mode, the following screen appears.



#### **GUI Language Select:**

Selects the display language used for the control screen and so forth

#### **Navigation Language Select:**

Selects the language used for navigation.

#### Text Language Select:

Selects the language used for tag text (song information).

#### 3 Touch [Enter].

#### NOTE

· To cancel the language setup, touch [Cancel].

## Touch panel adjustment

1 Touch [Touch] in the System Menu screen.

Touch Panel Adjustment screen appears.

2 Follow the instruction on the screen and touch the center of each .



- To cancel the touch panel adjustment, touch [Cancel].
- To reset to the initial status, touch [Reset].



A red indicator will blink on the unit after the ACC is set to OFF, warning potential thieves. If turned to "ON" (default), the security indicator on the front panel flashes when the vehicle ignition is off.

- Touch [Security] in the System Menu screen.
  - Security screen appears.
- 2 Touch [ON] or [OFF] of [SI].

## Setup memory

Audio Control, AV-IN SETUP, Camera, and Audio SETUP settings can be memorized. The memorized settings can be recalled at any time. For example, even when the settings are cleared due to replacement of the battery, the settings can be restored.

1 Touch [SETUP Memory] in the System Menu screen.

SETUP Memory screen appears.

2 Follow the instruction on the screen.



#### [Lock]/[Unlock]\*

Locks or unlocks the AV-IN SETUP, and Audio SETUP settings.

#### Yes

Memorizes or recalls the settings.

#### No

Cancels the function or memorization. The SETUP Menu screen appears again.

\* When [Lock] is selected, you cannot change the AV-IN SETUP, and Audio SETUP settings. Also, the locked key mark is displayed under each setting icon in the setup menu.

### 3 Follow the instruction on the screen.



#### Recall

Recalls the memorized settings.

#### Memory

Memorizes the current settings.

#### Clear

Clears the currently memorized settings.

#### Cancel

Quits memorization/recalling of settings.

### **Display Setup**

- 1 Touch [Menu] on any screen.
- **2 Touch [SETUP].**SETUP Menu screen appears.
- 3 Touch [Display].



Display Menu screen appears. See the following section for each setting.

- Adjust panel color (P.98)
- Changing background image (P.99)



### Panel color coordinate

You can set the screen and button illumination color.

The selectable items differ depending on the unit.

Touch [Color] in the Display Menu screen.

Color screen appears.

- 2 Touch [OFF] of [Panel Color Scan].
- 3 Touch [SET] of [Panel Color Coordinate].



Panel Color Coordinate screen appears.

#### NOTE

- You can touch [SET] or [Initialize] when [Panel Color Scan] is set to off.
- Touch [Initialize] to reset the settings to the default settings.
- 4 Touch the desired color.



#### Registering original color

You can register your original color.

1 Touch [Adjust] in the Panel Color Coordinate screen.

Panel Color RGB Coordinate screen appears.

2 Use [◄] and [►] to adjust each color value



3 Touch the desired preset key for 2 seconds.

#### Panel color scan

You can set the panel color to continuously scan through the color spectrum.

 Touch [ON] of [Panel Color Scan] in the Color screen.

Panel Color Scan is set to on.

## Changing background image

You can load an image from the connected USB device and set it for the background image.

Before operating this procedure, it is necessary to connect the device which has the image to load.


 Touch [Background] in the Display Menu screen.

Background screen appears.


2 Touch [STANDBY].



- **3 Touch [Memory] of [User Background].**User Background File Select screen appears.
- 4 Select the image to load.



5 Touch [Enter].



The selected image is loaded and the

display returns to the Background screen.

#### NOTE

- Touching [ ] rotates counter clockwise.
- Touching [ ] rotates clockwise.
- 6 Touch [Change] of [Background Change] in the Background screen.
- 7 Select an image for background and touch [Enter].

- See <u>Playable Media and Files (P.122)</u> for readable image specifications.
- Touching [Delete] in the Background screen deletes the background image. After you touch [Delete], a confirmation message appears. Follow the message and complete the operation.

### **Navigation Setup**

You can set navigation parameters.

- 1 Touch [Menu] on any screen.
- **2 Touch [SETUP].**SETUP Menu screen appears.
- 3 Touch [Navigation].



Navigation SETUP screen appears.

4 Set each item as follows.



#### **NAV Interrupt Speaker**

Selects speakers used for voice guidance of the navigation system.

Front L: Uses the front left side speaker for voice guidance.

Front R: Uses the front right side speaker for voice guidance.

Front All (Default): Uses both front speakers for voice guidance.

#### **NAV Voice Volume**

Adjusts the volume for voice guidance of the navigation system. Default is "20".


#### NAV Mute

Mutes the volume of rear speakers during voice guidance of the navigation system. Default is "ON".

### **Camera Setup**

You can set camera parameters.

- 1 Touch [Menu] on any screen.
- **2 Touch [SETUP].**SETUP Menu screen appears.
- 3 Touch [Camera].



Camera SETUP screen appears.

4 Set each item as follows.



#### **R-CAM Interruption**

Sets a method for switching the display. Setting values are ON and OFF.

ON: Switches to the rear view camera video display when shifting to reverse or pressing the <TEL>\*1 button for 1 second.

OFF (Default): Switches to the rear view camera video display when pressing the <TEL>\*1 button for 1 second.

\*1 [TEL Key Longer than 1 Second] must be set to "R-CAM". See *User interface (P.94)*.

#### NOTE

• To hear the sound from the rear view camera, set the "AV-IN Interface" to Rear camera. See <u>AV Input</u> Setup (P.101).


### **AV Input Setup**

You can set AV input parameters.

- 1 Touch [Menu] on any screen.
- **2 Touch [SETUP].** SETUP Menu screen appears.
- 3 Touch [Source].



- 4 Touch [AV-IN SETUP] in the list. AV-IN SETUP screen appears.
- 5 Set each item as follows.



#### AV-IN Interface\*1

Select the source connected to AV-IN.
Rear Camera: Select when the rear view
camera is connected.

AV-IN (Default): Select when AV device is connected.

#### AV-IN1 Name/AV-IN2 Name\*2


Sets a name to be displayed when you select a system that is connected via the AV INPUT port. Default is "VIDEO".

- \*1 This item can be set when in STANDBY source.
- \*2 AV-IN1 Name stays Rear Camera when selecting Rear Camera in AV-IN Interface.

## **AV Output Interface Setup**

You can select an AV source to be output at the AV OUTPUT port. Default is "VIDEO1".

- 1 Touch [Menu] on any screen.
- **2 Touch [SETUP].**SETUP Menu screen appears.
- 3 Touch [AV-OUT].



AV-OUT Interface screen appears.

4 Touch [◄] or [►] to set [AV-OUT] to VIDEO1, DISC, iPod, USB, Navigation, or OFF.

- Only when iPod is connected to this unit with KCA-iP202, "USB" can be selected as AV output source. For the connection setting, refer to <u>iPod/</u> <u>iPhone connection setup</u> (P.54).
- When selecting the Navigation, there are limitations below:
  - No audio is outputted.
  - Video is outputted only when the unit is displaying Navigation.

### **Software Information**


Check the software version of this unit.

- 1 Touch [Menu] on any screen.
- **2 Touch [SETUP].** SETUP Menu screen appears.
- 3 Touch [Software].



Software Information screen appears.

4 Confirm the software version. Touch [Update] as necessary.



#### NOTE

• For how to update the software, see the relevant update procedure manual which comes with the software.

## **C**ontrolling Audio

#### NOTE

• Each operation in this section can be started from the multi function menu.

You can adjust the various settings such as audio balance or subwoofer level.

- 1 Touch [Menu] on any screen.
- 2 Touch [Audio].

Audio screen appears.

See the following section for each setting.

- Setting audio (P.104)
- Controlling audio (P.108)
- Controlling equalizer (P.108)
- Performing zone control (P.110)
- Set sound effect (P.111)
- Set listening position (P.112)

## **Setting Audio**

1 Touch [Audio SETUP].



Audio SETUP screen appears.



See the following section for each setting.

- Set up speakers (P.105)
- Set up your car type (P.106)
- Select DSP (P.107)

## Speaker setup

You can select a speaker type and its size to get the best sound effects.

When the speaker type and size are set, the speaker crossover network is set automatically.

 Touch [Speaker Select] in the Audio SETUP screen.

Speaker Select screen appears.



2 Touch the speaker you wish to adjust and set each item as follows.



#### X'over

Displays the speaker crossover setup screen. You can adjust the crossover setup that was set automatically when you selected the speaker type.

For details, see <u>Crossover network setup</u> (P.106)

#### 3 Select a speaker size using [◄] and [►]. The speaker size is different depending on the speaker type and the unit.

#### Front

OEM, 3-1/2 inch, 4 inch, 4-3/4 inch, 5 inch, 6-1/2 inch, 6-3/4 inch, 7 inch, 4x6, 5x7, 6x8, 6x9, 7x10

#### Rear

None, OEM, 3-1/2 inch, 4 inch, 4-3/4 inch, 5 inch, 6-1/2 inch, 6-3/4 inch, 7 inch, 4x6, 5x7, 6x8, 6x9, 7x10

#### Subwoofer

None, 6 1/2 inch, 8 inch, 10 inch, 12 inch, 15 inch over

#### NOTE

• Select "None" if you have no speakers.

#### Crossover network setup

You can set a crossover frequency of speakers.

- 1 Touch the speaker to set the crossover in the Speaker Select screen.
- **2 Touch [X'over].**X'over screen appears.
- 3 Set each item as follows.



#### Phase\*1

Sets the phase of subwoofer output.
The phase is reversed 180 degrees when set to "Reverse". (When subwoofer is selected on Speaker Select screen)

#### **HPF FREO**

High Pass Filter adjustment. (When front or rear speaker is selected on Speaker Select screen)

#### **LPF FREQ**

Low Pass Filter adjustment. (When subwoofer is selected on Speaker Select screen)

#### Slope\*2

Sets a crossover slope.

- \*1 Only when "Subwoofer" is set to a mode other than "None" in <Speaker Setup>.
- \*2 Only when "LPF FREQ"/"HPF FREQ" is set to a mode other than "Through" in <X'over>.

## Car type setup

You can setup the car type and speaker network, etc.

1 Touch [Car Type] in the Audio SETUP screen.

Car Type screen appears.

2 Select your car type from the list.



#### NOTE

 If your car type is selected, the Delay Time Alignment is set automatically (for timing adjustment of sound output for each channel) to have the highest surround effects.

#### Speaker location setup

- 1 In the Car Type screen, touch [Location].
  Speaker Location screen appears.
- 2 Select the speaker locations using [▶].



#### **Front Speaker**

Select the location from "Door"/ "On Dash"/ "Under Dash".


#### **Rear Speaker**

Select the location from "Door"/"Rear Deck", "2nd Row"/"3rd Row" (Minivan, Minivan (Long)).

## DSP select

You can select whether using DSP (Digital Signal Processor) System.

1 Touch [Bypass] or [Through] of [DSP Select] in the Audio SETUP screen.



#### **Bypass**

There is no effect by DSP.

#### **Through**

There is an effect by DSP.

#### NOTE

• When the mode is set to [Bypass], DSP System cannot be adjusted.

### **Controlling General Audio**

#### 1 Touch [Audio Control].



#### 2 Set each item as follows.



#### Fader #/Balance #

Adjust the volume balance around the touched area.

[◄] and [►] adjust the right and left volume balance.

[▲] and [▼] adjust the front and rear volume balance.

#### **Volume Offset\***

Finely adjust the volume of the current source to minimize the difference in volume between different sources.

#### **Subwoofer Level**

Adjusts the subwoofer volume. This setting is not available when subwoofer is set to "None". See **Speaker setup (P.105)**.

#### **Bass Boost**

Sets the amount of bass boost among "OFF"/ "Level1"/ "Level2"/ "Level3".

\* If you have increased the volume first, then reduced the volume using the "Volume Offset", the sound generated if you suddenly switch to another source may be extremely loud.

### **Equalizer Control**

You can adjust equalizer by selecting the optimized setting for each category.

#### 1 Touch [Equalizer].



Equalizer screen appears.



#### **Controlling EQ curves**

1 Select EQ curve from [Natural], [Rock], [Pops], [Easy], [Top40], [Jazz], [Powerful], [iPod], and [User].



#### NOTE

• [iPod] is available only during iPod source.

#### Controlling equalizer manually

This setting cannot be performed when you select [iPod] in the Equalizer screen.

- 1 Touch [EQ] in the Equalizer screen.
- 2 Touch the screen and set the Graphic Equalizer as desired.



#### Gain level (light green boxed area)

Adjust the gain level by touching the each frequency bar.

Touching  $[\blacktriangleleft]$ ,  $[\blacktriangleright]$ ,  $[\blacktriangle]$  and  $[\blacktriangledown]$  can also adjust the level. Use  $[\blacktriangleleft]$  and  $[\blacktriangleright]$  to select a frequency, and  $[\blacktriangle]$  and  $[\blacktriangledown]$  to set the level.

#### **EQ INIT**

Returns to the previous level which the gain level is adjusted.

#### Flat

Tone curve becomes flat.

#### Bass EXT (Bass Extend Settings)

When turned on, the frequency lower than 62.5 Hz is set to the same gain level as 62.5 Hz.

#### Loudness

Sets the amounts of boost of low and high tones

"OFF", "ON"

#### **SW Level**

Adjusts the subwoofer volume. This setting is not available when subwoofer is set to "None". See *Speaker setup (P.105)*.

### **Zone Control**

You can select different sources for both front and rear positions in the vehicle.

#### 1 Touch [Zone Control].



Zone Control screen appears.

#### 2 Touch [Dual Zone].



#### 3 Set each source as follows.



#### [►] (Front Source, Rear Source)

Select the audio source for each.

#### [▼], [▲] (Rear VOL.)

Adjusts the rear channel volume.

#### [Single Zone]

Touch to turn off the dual zone function.

#### NOTE

- When the rear speaker sound is switched, the audio source that is output at the AV OUTPUT terminal is also switched to the same source.
- When the dual zone function is set to on, the following functions are not available.
- · Output from the subwoofer
- · Subwoofer Level/ Bass Boost (P.108)
- Equalizer Control/ Sound Effect/ Listening Position (*P.108*, *111*, *112*)
- DSP Bypass Control/ Speaker Setup/ Car Type Setup (P.107, 105, 106)
- Different sources from iPod/iPhone (apps) cannot be set as front source and rear source separately.
   Only one source (app) can be set as front and rear sources.

## **Sound Effect**

You can set sound effects.

### 1 Touch [Sound Effect].



Sound Effect screen appears.

# Drive Equalizer setting

The sound quality is automatically adjusted.

### 1 Touch [ON] or [OFF] of [Drive Equalizer].



The sound quality is automatically optimized to meet the current volume level.

### **Listening Position**

You can adjust the sound effects according to your listening position.

1 Touch [Position].



Position screen appears.

2 Select listening position from [Front R] (Right front), [Front L] (Left front), [Front All] (All front), and [All] using [◄] and [►].



# Position DTA control

You can fine-adjust your listening position.

- 1 In Position screen, touch [Adjust].
- 2 Select the speaker you wish to adjust by touching speaker icon.



3 Set DTA as follows.



[**◄**],[**▶**]

Adjust the settings of the DTA position.


#### Gain

Touch to adjust the gain of each speaker.

#### NOTE

- Make fine adjustment of the delay time of the speaker output specified here to have a more suitable environment for your vehicle.
- If you specify the distance from the center of the currently set listening position to every speaker, the delay time will be automatically computed and set.
  - ① Determine the center of the currently set listening position as the reference point.
  - ② Measure the distances from the reference point to the speakers.
  - ③ Calculate the differences between the distance of the furthest speaker and other speakers.
  - ④ Input the differences calculated in step ③ for individual speakers.
  - ⑤ Adjust gain for individual speakers. A sound image will be shifted to the speaker with increased gain.

Example: When [Front All] is selected as the listening position



### **Remote control**

This unit can be operated using the remote control.

#### **▲**CAUTION

- Put the remote control in a place where it will not move during braking or other operations. A
  dangerous situation could result, if the remote control falls down and gets wedged under the pedals
  while driving.
- Do not leave the battery near fire or under direct sunlight. A fire, explosion or excessive heat generation may result.
- Do not recharge, short, break up or heat the battery or place it in an open fire. Such actions may cause
  the battery to leak fluid. If spilled fluid comes in contact with your eyes or on clothing, immediately
  rinse with water and consult a physician.
- Place the battery out of reach of children. In the unlikely event that a child swallows the battery, immediately consult a physician.

### **Battery Installation**

If the remote control operates only over shorter distances or does not operate at all, it is possible that the batteries are depleted.

In such instances, replace the both batteries with new ones.

1 Insert two "AAA"/"R03"-size batteries with the ⊕ and ⊖ poles aligned properly, following the illustration inside the case.




### **Functions of the Remote control Buttons**



### Switching the operation mode

The functions operated from the remote control differ depending on the position of the mode switch.



#### **AUD** mode

Switch to this mode when controlling a selected source or tuner source, etc.

#### **DVD** mode

Switch to this mode when playing a disc media including DVD, VCD, and CD.

#### **NAV** mode

Switch to this mode when controlling navigation function.

#### NOTE

• When controlling a player that is not integrated in the unit, select "AUD" mode.

### Direct search mode

Using the remote control, you can jump directly to the desired file, track chapter, etc. with entering the number corresponding to the content.

#### NOTE

 This operation cannot be performed for USB device and iPod.

# 1 Press the <#BS> button several times until the desired content appears.

The available contents are different depending on the source.

#### DVD

Title number/Chapter number/Play time/Item number\*

\* You may not be able to use this function with some discs or scenes.

#### VCD 1.X and 2.X (PBC OFF)

Track number

#### VCD 2.X (PBC ON)

Scene number/number

#### **Music CD**

Track number/Play time

#### **Audio files**

Folder number/File number

#### Radio

Frequency value

#### **HD Radio tuner**

Frequency value/Channel number

#### SiriusXM


Channel number

- 2 Enter the number of the content you want to play using the numeric keypad.
- 3 For DVD or VCD, press the <ENTER> button.

For music CD or audio files, press the <POSITION> button.

For radio, press the <◄> or <▶> button.

The content you entered is played.



	Key Name	Location of the mode switch	Function
1	SRC	AUD, DVD	Switches to the source to be played. In hands-free mode, hangs up the phone.
2	NAV	_	Switches between the navigation and the source screens.
3 MENU		DVD	Stops playing and memorizes the last point where the disc stopped. The last point is deleted by pressing twice.
		NAV	Displays Main menu.
4	OUT, IN	NAV	Zooms in or out the navigation map.
During radio, HD F		AUD, DVD	Pauses the track or file, and resumes playing by pressing twice. During radio, HD Radio, and SiriusXM source in AUD mode, switches the seek mode.
		NAV	Displays the current position.
6 Cursor Key DVD Moves th		DVD	Moves the cursor in the DVD menu.
		NAV	Moves the cursor or scrolls the map.
7	ENTER	AUD, DVD	Performs the selected function.
		NAV	Registers the selected position.     Performs the selected function.
8	ROUTE M	AUD	Screen mode changes each time you press this key during video playback.
		DVD	Returns to the DVD top menu.
		NAV	Displays Route Option menu.

	Key Name	Location of the mode switch	Function	
9	VOICE	AUD	Switches navigation display on/off.	
		DVD	Displays the DVD menu. Turns the playback control on or off while playing VCD.	
		NAV	Speaks the voice guidance.	
10	VIEW	AUD, DVD	Switches the AV source to be output.	
		NAV	Switches between 2D and 3D map displays.	
11	MAP DIR	NAV	Switches between the heading up navigation and north up navigation map displays.	
12	▲/▼	AUD, DVD	Selects the folder to be played. During radio, HD Radio, and SiriusXM source in AUD mode, switches the bands to be received.	
13	<b>⋖</b> /▶	AUD, DVD	Selects the track or file to be played. During radio, HD Radio, and SIRIUS/XM source in AUD mode, switches to broadcast stations received by the unit.	
14	Numeric Keypad	AUD	Specifies the number to search in direct search. For details on the direct search mode, see <i>Direct search mode</i> ( <i>P.115</i> ).	
		DVD	<ul> <li>Press [1] [2] to fast forward/backward. Switches the fast forward/backward speed each time you press this key.</li> <li>Press [4] [5] to slow forward/backward. Switches the slow playback speed each time you press this key.*</li> <li>*DVD only</li> </ul>	
15	* +	DVD	Clears the number.	
16	# BS	AUD, DVD	Switches to the direct search mode. For details on the direct search mode, see <i>Direct search mode</i> (P.115).	
17	AUDIO	DVD	Switches the voice language each time you press this key.	
18	CANCEL	DVD	Displays previous screen.	
		NAV	Cancels the operations.	
19	SUBTITLE	DVD	Switches the subtitle language.	
20	C	_	When a call comes in, answers the call.	
21	ANGLE	DVD	Switches the picture angle each time you press this key.	
22	Vol ▲▼	_	Adjusts the volume.	
23	ZOOM	DVD	Switches the zoom ratio (2, 3, 4, Off) each time you press this key.	
24	2 ZONE	AUD, DVD	Switches the Dual Zone function on and off.	
25	R.VOL	_	Adjusts volume at rear when the Dual Zone function is on.	
26	ATT	-	Lowers the volume by pressing the key once. Restores the previous volume by pressing the key twice.	

# Troubleshooting

## **Problems and Solutions**

If any trouble occurs, first check the following table for possible problems.

- Some functions of this unit may be disabled by some settings made on this unit.
- What might seem to be a malfunction in your unit may just be the result of slight misoperation or miswiring.

# About settings

Problem	Reason	Solution
<ul><li>Cannot set up the subwoofer.</li><li>Cannot set up subwoofer phase.</li></ul>	Subwoofer is not set to on.	Set the subwoofer to on. See <b>Speaker setup (P.105)</b> .
<ul><li>No output from the subwoofer.</li><li>Cannot set up the low pass filter.</li><li>Cannot set up the high pass filter.</li></ul>	The dual zone function is enabled.	Set the dual zone function to off. See <b>Zone Control (P.110)</b> .
Cannot select the output destination of the subsource in the dual zone.     Cannot adjust the volume of the rear speakers.	The dual zone function is disabled.	Set the dual zone function to on. See <b>Zone Control (P.110)</b> .
<ul><li>Cannot set up the equalizer.</li><li>Cannot set up the crossover</li></ul>	The dual zone function is enabled.	Set the dual zone function to off. See <b>Zone Control (P.110)</b> .
network.	"DSP Select" is set to "Bypass".	Set "DSP Select" to "Through". See <b>DSP select (P.107)</b> .

# About audio operations

Problem	Reason	Solution
Radio reception is poor.	The car antenna is not extended.	Pull out the antenna all the way.
	The antenna control wire is not connected.	Connect the wire correctly. See "Connection" in the Quick Start Guide.
Cannot play audio files stored in a disc.	"CD Read" is set to "2".	Set "CD Read" to "1". See <i>Disc setup (P.28)</i> .
Cannot select a folder.	The random play function is enabled.	Turn off the random function.
Cannot perform repeat play during VCD playback.	The PBC function is enabled.	Turn off the PBC function.
The specified disc does not play, but another one plays instead.	The disc is quite dirty.	Clean the disc. See <i>Precautions on handling discs</i> (P.4).
	The disc is severely scratched.	Try another disc instead.

Problem	Reason	Solution
The sound skips when an audio file is being played.	The disc is scratched or dirty.	Clean the disc. See <i>Precautions on handling discs</i> (P.4).
	The recording condition is bad.	Record the file again or use another disc.



Problem	Reason	Solution
The Touch Sensor Tone doesn't sound.		The Touch Sensor Tone cannot be output from the preout jack.

## **Error Messages**

When you fail to operate the unit correctly, the cause of the failure appears as the message on the screen.

<b>Error Message</b>	Cause	Solution
Protect Protective circuit has been activated because a speaker cord has shorted or it has come in contact with the car chassis.		Wire or insulate the speaker cord as appropriate and then push the <reset> button (P.121).</reset>
Hot Error	When the internal temperature of this unit rises to 60°C or more, the protection circuit is activated and you may not be able to operate the unit.	Use the unit again after reducing the temperature of the unit.
Mecha Error	The disc player is malfunctioning.	Eject the disc and try inserting it again. Contact the Kenwood dealer if this indicator continues blinking or the disc cannot be ejected.
Disc Error	An unplayable disc is inserted.	Change the disc. See <i>Playable Media and Files (P.122)</i> .
Read Error	The disc is quite dirty.	Clean the disc. See <b>Precautions on handling discs (P.4)</b> .
	Disc is upside down.	Load the disc with the labeled side up.
Region Code Error	The disc you wanted to play has a region code that cannot be played with this unit.	See <b>Region Codes in the World (P.128)</b> or try another disc.
Parental Level The disc you wanted to play has a higher level than the parental level you set.		Set the parental level. See <u>Parental level (P.28)</u> .
Error 07–67 The unit is not operating correctly due to some reason or other.		Push the unit's Reset button. If the "Error 07–67" message does not disappear, see your nearest Kenwood dealer.
No Device (USB device, Bluetooth audio player)	The USB device is selected as a source although no USB device is connected.	Change the source to any source other than USB/iPod. Connect a USB device, and change the source to USB again.

<b>Error Message</b>	Cause	Solution
Disconnected (iPod)	The iPod/Bluetooth audio player is selected as a source although no iPod/Bluetooth audio player is connected.	Change the source to any source other than iPod/Bluetooth. Connect an iPod/Bluetooth audio player, and change the source to iPod/Bluetooth again.
No Media file	The connected USB device contains no playable audio file. Media was played that doesn't have data recorded that the unit can play.	See <b>Playable Media and Files (P.122)</b> and try another USB device.
USB Device Error!!	The connected USB device is rated a current capacity higher than the	Check the USB device. Some trouble may have occurred to the connected USB device.
	allowable limit.	Change the source to any source other than USB. Remove the USB device.
Authorization	Connection to the iPod has failed.	Remove the iPod and then reconnect it.
Error		• The unit does not support the iPod. See <b>Connectable iPod/iPhone (P.124)</b> .
Update your iPod	The iPod's software is an older version which the unit can not support.	The unit may not support the connected iPod model. Confirm that the software for the iPod is the latest version. See Connectable iPod/iPhone (P.124).
Navigation Error. Please turn on power again later.	The communication error has occurred due to severely cold temperature.	Turn on power again after warming your car interior.
Check Application	The Aha application is stopped.	Start the Aha application of the your device.
Please update your Aha application	The Aha application is an older version which the unit can not support.	Confirm that the Aha application is the latest version.

# SiriusXM


Check Tuner	A SiriusXM tuner is not connected to this unit.	Check that the connected SiriusXM Connect Vehicle Tuner is connected.
Subscription Updated - Press Return To Continue	The SiriusXM subscription has been renewed.	Pressing the Control knob will clear the error message.
Channel Not The currently selected channel is unavailable.		_
Ch The currently selected channel is not subscribed to.		_
Check Antenna No antenna is connected to the Sirius XM tuner.		Check that an antenna is connected to the SiriusXM tuner.
No Signal No SiriusXM radio signal is received.		_

### **Resetting the Unit**

If the unit or the connected unit fails to operate properly, reset the unit.

#### 1 Press the <Reset> button.

The unit returns to factory settings.



#### NOTE

- Disconnect the USB device before pressing the <Reset> button. Pressing the <Reset> button with the USB device connected can damage the data stored in the USB device. For how to disconnect the USB device, see <a href="#">How to Play Media (P.11)</a>.
- When the unit is turned on after resetting, the Initial SETUP screen appears. See *Initial setup (P.9)*.

# **A**ppendix

## **Playable Media and Files**

You can play various kinds of media and files on this unit.

### Lis

### List of playable discs

Disc types	Standard	Support	Remark	
DVD	DVD Video	0		
	DVD Audio	×		
	DVD-VR	×		
	DVD-R*1	0	MP3/WMA/AAC/MPEG1/MPEG2 playback     Multi-border/Multisession playback (Playback depends on authoring conditions)	
	DVD-RW	0		
	DVD+R	0		
	DVD+RW	0		
	DVD-R DL (Dual layer)	0	Only video format	
	DVD+R DL (Double layer)	0		
	DVD-RAM	×		
CD	Music CD*1	0	CD-TEXT	
	CD-ROM	0	MP3/WMA/AAC/MPEG1/MPEG2 playback	
	CD-R	0	Multisession is supported.	
	CD-RW	0	Packet write is not supported.	
	DTS-CD	×		
	Video CD (VCD)	0		
	Super video CD	×		
	Photo CD	×		
	CD-EXTRA	Δ	Only music CD session can be played.	
	HDCD	0		
	CCCD	×		
Others	Dualdisc	×		
	Super audio CD	Δ	Only CD layer can be played.	

<sup>\*1</sup> Incompatible with 8 cm (3 inch) discs.

O: Playback is possible.

 $<sup>\</sup>triangle$ : Playback is partly possible.

x : Playback is impossible.

#### ■ Use of DualDisc

When playing a "DualDisc" on this unit, the surface of the disc that is not played may be scratched while the disc is inserted or ejected. Since the music CD surface does not conform to the CD standard, playback may be impossible.

(A"DualDisc" is a disc with one surface containing DVD standard signals and the other surface containing music CD signals.)

#### ■ About disc format

The disc format should be the one of the following.

- ISO 9660 Level 1/2
- Joliet
- Romeo
- · Long file name



# The following audio, video, and picture files are supported.

#### Audio files

- · AAC-LC (.m4a)
- MP3 (.mp3)
- · WMA (.wma)
- Linear PCM (WAVE) (.wav)
   Mass-storage-class USB device only
- FLAC (.flac)
   Mass-storage-class USB device only

#### NOTE

- If music of normal CD and other playback systems are recorded in the same disc, only the playback system recorded at the first setout is played.
- WMA and AAC of which is covered with DRM cannot be played.
- Although the audio files are complied with the standards listed above, the play may be impossible depending on the types or conditions of media or device.
- An online manual about audio files is put on the site, www.kenwood.com/cs/ce/audiofile/.
   On this online manual, detailed information and notes which are not written in this manual are provided. Make sure to read through the online manual as well.

#### ■ Video files

- MPEG1 (.mpg, .mpeg, .m1v\*)
   \*Mass-storage-class USB device only
- MPEG2 (.mpg, .mpeg, .m2v\*) \*Mass-storage-class USB device only
- H.264/MPEG-4 AVC (.mp4, .m4v) Mass-storage-class USB device only
- WMV 9 (.wmv, .m2ts) Mass-storage-class USB device only

#### ■ Picture files

Only picture files in USB device can be displayed. Files stored in disc media is not supported.


- · JPEG (.jpg, .jpeg)
- · PNG (.png)
- BMP (.bmp)

#### NOTE

BMP and PNG can be set only as wallpaper.

#### ■ Playing order of files

In the example of folder/file tree shown below, the files are played in the order from ① to ⑩.



### **Appendix**



### Connectable iPod/iPhone

# The following models can be connected to this unit.

Made for

- iPhone 5s
- iPhone 5c
- iPhone 5
- iPhone 4S
- iPhone 4
- iPhone 3GS
- · iPhone 3G
- iPhone
- iPod touch (5th generation)
- · iPod touch (4th generation)
- · iPod touch (3rd generation)
- · iPod touch (2nd generation)
- iPod touch (1st generation)
- iPod classic
- · iPod with video
- · iPod nano (7th generation)
- · iPod nano (6th generation)
- · iPod nano (5th generation)
- · iPod nano (4th generation)
- iPod nano (3rd generation)

#### NOTE

- For the details of the necessary cable and adapter to connect with iPod/iPhone, refer to Music/ Video/Picture Basic Operation (P.30).
- For the conformity information on iPod/iPhone software,

access www.kenwood.com/cs/ce/ipod/.

- By connecting your iPod/iPhone to this unit with an optional accessory iPod connection cable KCA-iP202 or KCA-iP102, you can supply power to your iPod/iPhone as well as charge it while playing music. However, the power of this unit must be on.
- If you start playback after connecting the iPod, the music that has been played by the iPod is played first.
  - In this case, "Reading" is displayed without displaying a folder name, etc. Changing the browse item will display a correct title, etc.
- When the iPod is connected to this unit, "KENWOOD" or "✓" is displayed on the iPod to indicate that you cannot operate the iPod.

# Us

### **Usable USB device**

You can use a mass-storage-class USB device on this unit.

The word "USB device" appearing in this manual indicates a flash memory device and digital audio players can be recognized as mass-storage.

#### ■ About file system

The file system should be the one of the following.

- FAT16
- FAT32

#### NOTE

- When the USB device is connected to this unit, it can be charged through the USB cable.
- Install the USB device in the place where it will not affect safe driving.
- You cannot connect a USB device via a USB hub and Multi Card Reader.
- Take backups of the audio files used with this unit. The files can be erased depending on the operating conditions of the USB device.
   We shall have no compensation for any damage arising from any erased data.
- No USB device comes with this unit. You need to purchase a commercially available USB device.
- When connecting the USB device, usage of the CA-U1EX (option) is recommended. (However, maximum supply current of CA-U1EX is 500mA.) Normal playback is not guaranteed when a cable other than the USB compatible cable is used.

### **Status Bar Indicator Items**

Shown below is a list of indicators displayed on the status bar in the screen.  $\label{eq:control}$ 

Current status of this unit is displayed on the bar.



#### ■ General

#### ATT

The attenuator is active.

#### DUAL

The dual zone function is on.

#### TEL

Indicates the connection state of the Bluetooth hands-free unit.

- · White: Connected
- · Orange: Not connected

#### MUTE

The mute function is active.

#### LOUD DNX6 DNX5

The loudness control function is on.

#### ■ DVD/CD

#### **FO-REP**

Folder repeat function is on.

#### IN

A disc is inserted.

- · White: A Disc is inside the unit.
- Orange: Error at the disc player

#### **VIDEO**

Identifies the video file.

#### MUSIC

Identifies the music file.

#### **RDM**

The random function is on.

#### **REP**

The repeat function is on.

#### **C-REP**

The chapter repeat function is on.

#### T-REP

The title repeat function is on.

#### VCD

#### 1chLL/2chLL

Identifies the left audio output of channel 1 or 2

Status bar

#### 1chLR/2chLR

Identifies the monaural audio output of channel 1 or 2.

#### 1chRR/2chRR

Identifies the right audio output of channel 1 or 2.

#### 1chST/2chST

Identifies the stereo audio output of channel 1 or 2.

#### LL

Identifies the left audio output.

#### LR

Identifies the monaural audio output.

#### RR

Identifies the right audio output.

#### **STEREO**

Identifies the stereo audio output.

#### PBC

The PBC function is on.

#### **SVCD**

Identifies the Super Video CD.

#### VER1

The VCD version is 1.

#### VER2

The VCD version is 2.

REP

The repeat function is on.

**■** USB

**FO-REP** 

The folder repeat function is on.

**VIDEO** 

Identifies the video file.

**MUSIC** 

Identifies the music file.

PICTURE

Identifies the picture file.

**RDM** 

The random function is on.

REP

The repeat function is on.

**PLST** 

The play list mode is selected now.

■ iPod

MUSIC

Identifies the music file.

VIDEO

Identifies the video file.

RDM

The random function is on.

A-RDM

The album random function is on.

REP

The repeat function is on.

■ HD Radio reception

AUTO1

Seek mode is set to AUTO1.

AUTO2

Seek mode is set to AUTO2.

**MANUAL** 

Seek mode is set to MANUAL.

HD

HD Radio station is being received.

M/S

A multicast digital broadcast is being received.

ANALOG

An analog broadcast is being received.

DIGITAL

A digital broadcast is being received.

ST

A stereo broadcast is being received.

■ SiriusXM

SEEK1


Seek mode is set to SEEK1.

SEEK2

Seek mode is set to SEEK2.

### **Region Codes in the World**

The DVD players are given a region code according to the country or area it is marketed, as shown in the following map.



#### ■ DVD disc marks



Indicates a region number. The discs with this mark can be played with any DVD player.



Indicates the number of audio languages recorded. Up to 8 languages can be recorded in a movie. You can select a favorite language.



Indicates the number of subtitled languages recorded. Up to 32 languages can be recorded.



If a DVD disc has scenes shot from multiple angles, you can select a favorite angle.

### 16:9 LB

Indicates the type of screen for the image. The left mark indicates that a wide image picture (16:9) is displayed on a standard TV set screen (4:3) with a black band at both the top and bottom of the screen (letter box).

### ■ Operation regulatory marks

With this DVD, some functions of this unit such as the play function may be restricted depending on the location where the DVD is playing. In this case, the following marks will appear on the screen. For more information, refer to the disc manual.



### ■ Discs with limited period of use

Do not leave discs with a limited period of use in this unit. If you load an already expired disc, you may not be able to remove it from this unit.

# **DVD Language Codes**

Code	Language
aa	Afar
ab	Abkhazian
af	Afrikaans
am	Amharic
ar	Arabic
as	Assamese
ay	Aymara
az	Azerbaijani
ba	Bashkir
be	Byelorussian
bg	Bulgarian
bh	Bihari
bi	Bislama
bn	Bengali, Bangla
bo	Tibetan
br	Breton
са	Catalan
СО	Corsican
CS	Czech
су	Welsh
da	Danish
de	German
dz	Bhutani
el	Greek
en	English
eo	Esperanto
es	Spanish
et	Estonian
eu	Basque
fa	Persian
fi	Finnish
fj	Fiji
fo	Faroese
fr	French
fy	Frisian
ga	Irish
gd	Scots Gaelic
gl	Galician
gn	Guarani
gu	Gujarati
ha	Hausa
he	Hebrew
hi	Hindi
hr	Croatian
hu	Hungarian
hy	Armenian

Code	Language
ia	Interlingua
ie	Interlingue
ik	Inupiak
id	Indonesian
is	Icelandic
it	Italian
ja	Japanese
jv	Javanese
ka	Georgian
kk	Kazakh
kl	Greenlandic
km	Cambodian
kn	Kannada
ko	Korean
ks	Kashmiri
ku	Kurdish
ky	Kirghiz
la	Latin
lb	Luxembourgish
ln	Lingala
lo	Laotian
lt	Lithuanian
lv	Latvian, Lettish
mg	Malagasy
mi	Maori
mk	Macedonian
ml	Malayalam
mn	Mongolian
mo	Moldavian
mr	Marathi
ms	Malay
mt	Maltese
my	Burmese
na	Nauru
ne	Nepali
nl	Dutch
no	Norwegian
ос	Occitan
om	(Afan) Oromo
or	Oriya
ра	Punjabi
pl	Polish
ps	Pashto, Pushto
pt	Portuguese
QLI.	Quechua
qu	Queeriuu

Code	Language
rn	Kirundi
ro	Romanian
ru	Russian
rw	Kinyarwanda
sa	Sanskrit
sd	Sindhi
sg	Sangho
sh	Serbo-Croatian
si	Singhalese
sk	Slovak
sl	Slovenian
sm	Samoan
sn	Shona
so	Somali
sq	Albanian
sr	Serbian
SS	Siswati
st	Sesotho
	Sundanese
SU	Swedish
SV	
SW	Swahili
ta	Tamil
te	Telugu
tg	Tajik
th	Thai
ti	Tigrinya
tk	Turkmen
tl	Tagalog
tn	Setswana
to	Tongan
tr	Turkish
ts	Tsonga
tt	Tatar
tw	Twi
uk	Ukrainian
ur	Urdu
uz	Uzbek
vi	Vietnamese
VO	Volapuk
wo	Wolof
xh	Xhosa
уо	Yoruba
zh	Chinese
ZU	Zulu

### **Specifications**

#### ■ Monitor section

#### Picture Size

: 6.1 inches (diagonal) wide

:136.2 mm (W) x 72.0 mm (H)

5-6/16 x 2-13/16 inch

#### **Display System**

: Transparent TN LCD panel

#### **Drive System**

:TFT active matrix system

#### Number of Pixels

: 1.152.000 (800H x 480V x RGB)

#### **Effective Pixels**

: 99.99 %

#### Pixel Arrangement

: RGB striped arrangement

#### **Back Lighting**

: LED

#### ■ DVD player section

#### D/A Converter

· 24 bit

#### Audio Decoder

: Linear PCM/ Dolby Digital/ MP3/ WMA/ AAC

### Video Decoder

: MPEG1/ MPEG2

#### Wow & Flutter

: Below Measurable Limit

#### Frequency Response

• 96 kHz: 20 - 20.000 Hz

• 48 kHz: 20 – 20,000 Hz

• 44.1 kHz: 20 - 20,000 Hz

#### **Total Harmonic Distortion**

: 0.010 % (1 kHz)

### S/N Ratio (dB)

: 90 dB (DVD-Video 96 kHz)

#### Dynamic Range

: 91 dB (DVD-Video 96 kHz)

#### Disc Format

: DVD-Video/ VIDEO-CD/ CD-DA

#### Sampling Frequency

: 44.1/48/96 kHz

#### Quantifying Bit Number

: 16/20/24 bit

#### ■ USB interface section

#### USB Standard

: USB 2.0 High Speed

#### File System

: FAT 16/32

#### Maximum Power Supply Current

: DC 5 V .... 1 A

#### D/A Converter

· 24 Bit

#### Audio Decoder

: MP3/WMA/AAC/WAV/FLAC

#### Video Decoder

· MPEG1/ MPEG2/ MPEG4/ WMV/ H 264

#### ■ Bluetooth section

#### Technology

: Bluetooth Ver.3.0+EDR

#### Frequency

: 2.402 - 2.480 GHz

### **Output Power**

: +4dBm (MAX), 0dBm (AVE), Power Class2

#### Maximum Communication range

: Line of sight approx. 10m (32.8 ft)

#### Audio Codec

SBC/ AAC/ MP3

#### Profile

- · HFP (V1.6) (Hands Free Profile)
- · SPP (Serial Port Profile)
- · A2DP (Advanced Audio Distribution Profile)
- · AVRCP (V1.4) (Audio/Video Remote Control Profile)
- · HID (Human Interface Device Profile)
- · PBAP (Phonebook Access Profile)
- · GAP (Generic Access Profile)
- Multi Profile support

#### ■ HDMI/ MHL section

#### **HDMI**

: HDMI Type-A

#### MHL Supported Version

: MHL 2

#### MHL Maximum Power Supply Current

: DC 5 V .... 900 mA

#### ■ DSP section

#### Graphics equalizer

Band: 7 Band

Frequency (BAND1 - 7)

: 62.5/ 160/ 400/ 1k/ 2.5k/ 6.3k/ 16k Hz

#### Gain

:-9/-8/-7/-6/-5/-4/-3/-2/-1/0/1/2/3/4/5/6/7/8/9 dB

#### 2Way X'Over

#### High pass filter

Frequency: Through, 50/60/80/100/120/150/180/

220 Hz

Slope: -6/-12/-18/-24 dB/Oct.

#### Low pass filter

Frequency: 50/60/80/100/120/150/180/220 Hz,

Through

Slope: -6/-12/-18/-24 dB/Oct.

#### Position

#### Front / Rear / Subwoofer Delay

: 0 - 20.0ft (0.07ft Step)

Gain

:-8 - 0 dB

#### Subwoofer level

:-50 - +10 dB

#### ■ Digital FM tuner section

#### Frequency Range (step)

: 87.9 MHz - 107.9 MHz (200 kHz)

#### Frequency Response (± 3.0 dB)

: 20 Hz - 20 kHz

#### S/N Ratio

: 75 dB (STEREO)

#### ■ Digital AM tuner section

#### Frequency Range (step)

: 530 kHz - 1700 kHz (10 kHz)

#### Frequency Response (± 3.0 dB)

: 40 Hz - 15 kHz

#### S/N Ratio (dB)

: 75 dB (STEREO)

#### ■ FM tuner section

#### Frequency Range (step)

: 87.9 MHz - 107.9 MHz (200 kHz)

#### Usable Sensitivity

(S/N: 30 dB)

: 7.2 dBf (0.8 μV/ 75 Ω)

#### Quieting Sensitivity (S/N: 50 dB)

(S/N:50 dB)

: 10.2 dBf (1.13 μV/ 75 Ω)

#### Frequency Response (± 3.0 dB)

: 30 Hz – 15 kHz

#### S/N Ratio (dB)

: 75 dB (MONO)

#### Selectivity (± 400 kHz)

: Over 80 dB

### Stereo Separation

: 45 dB (1 kHz)

#### ■ AM tuner section

### Frequency Range (step)

: 530 kHz - 1700 kHz (10 kHz)

#### **Usable Sensitivity**

: 28 dBµ

#### **Appendix**

#### ■ Video section

Color System of External Video Input

: NTSC/PAL

External Video Input Level (RCA jack)

: 1 Vp-p/ 75 Ω

External Audio Max Input Level (RCA/mini jack)

: 2 V/ 25 kΩ

Video Input Level (RCA jacks)

: 1 Vp-p/ 75 Ω

Video Output Level (RCA jacks)

: 1 Vp-p/ 75 Ω

Audio Output Level (RCA jacks)

: 1.2 V/ 10 kO

■ Audio section

Maximum Power (Front & Rear)

:50 W x 4

Full Bandwidth Power (Front & Rear) (4  $\Omega,$  14.4 V,

1 % THD)

: 22 W x 4

Preout Level (V)

: 2 V/ 10 k $\Omega$ 

Preout Impedance

: ≤ 600 Ω

Speaker Impedance

:4-8Ω

### ■ Navigation section

#### Receiver

: High-sensitivity GPS receiver

#### Reception Frequency

: 1575.42 MHz (C/A code)

#### **Acquisition Times**

Cold: 29 seconds (typ)

(All satellites at -130 dBm Without aiding)

#### Update Rate

: 1/second, continuous

#### Accuracy

Position: <2.5 meters, CEP, at -130 dBm

Velocity: 0.1 meter/sec

#### Position Method

: GPS

#### Antenna

: External GPS antenna

#### ■ General

#### Operating Voltage

: 14.4 V (10.5 - 16 V allowable)

#### **Maximum Current Consumption**

:10 A

#### Installation Dimensions (W x H x D)

: 181.7 x 112.2 x 160.3 mm

7-2/16 x 4-6/16 x 6-5/16 inch

#### Operational Temperature Range

:-10 °C - +60 °C

#### Weight

: 2.0 kg (4.4 lbs)

#### NOTE

 Although the effective pixels for the liquid crystal panel is given as 99.99% or more, 0.01% of pixels may not light or may light incorrectly.

Specifications subject to change without notice.

### **About this Unit**

### ■ Copyrights

- The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by JVC KENWOOD Corporation is under license.
   Other trademarks and trade names are those of their respective owners.
- The "AAC" logo is a trademark of Dolby Laboratories.
- "Made for iPod" and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone may affect wireless performance.
- iPhone, iPod, iPod classic, iPod nano, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
- Sirius, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. All rights reserved.
- HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. HD Radio™ and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.
- is a trademark of DVD Format/Logo Licensing Corporation registered in the U.S., Japan and other countries.
- This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.
- Manufactured under license from Dolby Laboratories.
   Dolby and the double-D symbol are trademarks of Dolby Laboratories.
- · Android is a trademark of Google Inc.
- BlackBerry®, RIM®, Research In Motion® and related trademarks, names and logos are the property of Research In Motion Limited and are registered and/or used in the U.S. and countries around the world. Used under license from Research In Motion I imited.
- Adobe, Acrobat and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.
- QR Code ® is registered trademarks of DENSO WAVE INCORPORATED in JAPAN and other countries.
- The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI logo are trademarks or registed trademarks of HDMI Licensing LLC in the United States and other countries.
- · MHL and the MHL logo are a trademark or registered

- trademark of MHL, LLC.
   Incorporates MHL 2
- · "aupeo" is a trade mark of Aupeo Ltd.
- THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (¡)ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (¡¡)DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, LI.C. SEE <a href="http://www.mpegla.com">http://www.mpegla.com</a>
- · THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (;) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE, ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL, INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA, LLC, SEE HTTP:// WWW.MPEGLA.COM.
- libFLAC
   Copyright (C) 2000,2001,2002,2003,2004,2005,2006,20
   07,2008,2009 Josh Coalson
   Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:
- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND ONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR

#### Return to the Top page

#### **Appendix**

BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

#### · About Pandora®:

Requirements for listening to the Pandora® are as follows:

#### iPhone or iPod touch

- Use an Apple iPhone or iPod touch running under iOS3 or later.
- Search for "Pandora" in the Apple App Store to find and install the most current version of the Pandora® application on your device.

#### Android™

• Visit the Google play and search for Pandora to install.

#### BlackBerry®

- Visit www.pandora.com from the built in browser to download the Pandora application.
- Bluetooth must be built in and the following profiles must be supported.
  - SPP (Serial Port Profile)
  - A2DP (Advanced Audio Distribution Profile)

#### NOTE

- In the application on your device, log in and create an account with Pandora.
- (If you are not already a registered user, an account can also be created at www.pandora.com.)
- Internet connection by LTE, 3G, EDGE, or WiFi.
- Pandora® is only available in the United States, Australia, and New Zealand.
- Because Pandora® is a third-party service, the specifications are subject to change without prior notice. Accordingly, compatibility may be impaired or some or all of the services may become unavailable.
- Some functions of Pandora® cannot be operated from this unit.
- For issues using the application, please contact Pandora® at pandora-support@pandora.com.

#### · About iHeartRadio®:

Requirements for using iHeartAuto  $^{\!\top\!\!}$  are as follows:

#### iPhone or iPod touch

- Use an Apple iPhone or iPod touch running iOS5 or later.
- Search for "iHeartAuto" in the Apple App Store to find and install the most current version of the iHeartAuto™ application on your device.

#### Android™

- Use an Android device with firmware 2.2 or later.
- Search for "iHeartAuto" on Google play to find and install the most current version of the iHeartAuto™ application on your device.

#### Note

- iHeartRadio® is available only in the United States and U.S. Territories
- For the best application experience, a 3G/4G or Wi-Fi connection is recommended.
- Because iHeartAuto™ is a third-party service, the specifications are subject to change without prior notice. Accordingly, compatibility may be impaired or some or all of the services may become unavailable.
- $\bullet$  Some functions of iHeartRadio  $^{\circ}$  cannot be operated from this unit.
- If you experience issues while using the application, please contact iHeartRadio® Customer Care at http://help.iheartradio.com.
- iHeartRadio® and iHeartAuto™ are trademarks owned by Clear Channel Broadcasting, Inc. All uses are authorized under license.

#### **Appendix**

#### **■ FCC WARNING**

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

#### NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment may cause harmful interference to radio communications, if it is not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **ACAUTION**

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

In compliance with Federal Regulations, following are reproductions of labels on, or inside the product relating to laser product safety.

JVC KENWOOD Corporation 2967-3, ISHIKAWA-MACHI, HACHIOJI-SHI, TOKYO, JAPAN

THIS PRODUCT COMPLIES WITH DHHS RULES 21 CFR SUBCHAPTER J IN EFFECT AT DATE OF MANUFACTURE.

Location: Top plate

#### ■ IC (Industry Canada) Notice

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1)This device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC: " before the certification/ registration number only signifies that the Industry Canada technical specification were met.

#### **ACAUTION**

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated keeping the radiator at least 20cm or more away from person's body (excluding extremities: hands, wrists, feet and ankles).

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

• Contains Transmitter Module FCC ID: YZP-RBFAC 21XX

Contains Transmitter Module

IC: 7414A-RBFAC21XX

#### ■ CALIFORNIA, USA

This product contains a CR Coin Cell Lithium Battery which contains Perchlorate Material – special handling may apply.

See www.dtsc.ca.gov/hazardouswaste/perchlorate.

■ Información acerca de la eliminación de equipos eléctricos y electrónicos al final de la vida útil (aplicable a los países que hayan adoptado sistemas independientes de recogida de residuos)



Los productos con el símbolo de un contenedor con ruedas tachado no podrán ser desechados como residuos domésticos.

Los equipos eléctricos y electrónicos al final de la vida útil, deberán ser reciclados en instalaciones que puedan dar el tratamiento adecuado a estos productos y a sus subproductos residuales correspondientes. Póngase en contacto con su administración local para obtener información sobre el punto de recogida más cercano. Un tratamiento correcto del reciclaje y la eliminación de residuos ayuda a conservar los recursos y evita al mismo tiempo efectos perjudiciales en la salud y el medio ambiente.

#### ■ Para cumplimiento de la COFETEL:

"La operación de este equipo esta sujeta a las siguientes dos condiciones:

(1) es posible que este equipo o dispositivo no cause interferencia perjudicial y

(2) este equipo o dispositivo debe aceptar cualquier interferencia.

incluyendo la que pueda causar su operación no deseada."

# ■ Informação sobre a eliminação de pilhas

Este produto não deve ser eliminado como lixo doméstico geral. Devolva a pilha usada ao revendedor ou entidade autorizada para que a mesma seja devolvida ao fabricante ou importador.

A reciclagem e a eliminação de lixo de maneira apropriada ajudarão a conservar os recursos naturais ao mesmo tempo que prevenirão os efeitos prejudicais à nossa saúde e ao meio ambiente.









PERSONAL RADIO



















PSD)

HD2/HD3

Bookmark

Digital Sound

Artist Experience

